
Driver's Handbook



Driver's Handbook

JAGUAR CARS LIMITED, as manufacturers, are dedicated to the design and production of vehicles which meet the expectations of the world's most discerning purchasers.

To complement the features, systems and technology of your new vehicle we have produced this Driver's Handbook. In it we have undertaken to make the control of complex systems easy to understand and operate.

The information contained herein applies to a range of vehicles and not to a specific vehicle. For the specification of a particular vehicle, owners should consult their Jaguar Dealer.

The Manufacturer reserves the right to vary its specifications with or without notice, and at such times and in such manner as it thinks fit. Major as well as minor changes may be involved in accordance with the Manufacturer's policy of constant product improvement.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form, electronic, mechanical, photocopying, recording or other means without prior written permission from the Service Division of Jaguar Cars Limited.

Contents

1. Introduction

Jaguar Dealers	1-1
Genuine Jaguar Parts and Accessories	1-2
Safety Precautions	1-3
Safety, Warning and Caution Labels	1-4
Vehicle Identification	1-6

2. Security

Key Identification and Locks	2-2
Key-ring Transmitter	2-5
Luggage Compartment	2-8
Alarms and Audible Signals	2-10
Security System Features	2-11
Panic Alarm (Dealer option)	2-11
Radio Frequency Approval	2-13

3. Instruments - Controls

Warning Lights	3-3
Message Centre	3-8
Warning and Information Messages	3-9
Trip Computer	3-12
Automatic Transmission	3-15
'J' Gate Selector	3-15
Cruise (Speed) Control (where fitted)	3-19
Window Operation	3-22
Exterior Lighting	3-25
Interior Lighting	3-28
Handbrake	3-29
Windscreen Wipers and Washers	3-30
Rain Sensitive Wiper Operation (when fitted)	3-30
Horns	3-32
Audible Warnings	3-33

Contents

4. Pre-driving

Seats – Adjustments and Driving Position Memory	4-1
Driving Position Memory System (where fitted)	4-3
Steering Column Tilt and Reach Adjustment	4-4
Rear View Mirrors	4-6
Inertia Switch	4-8
Ignition/Starter Switch and Steering Lock	4-9
Fuel Filler Flap and Cap	4-11
Fuel Tank Filling	4-12
Occupant Protection – Seat Belts and Airbags	4-13
Inertia Reel Mechanism Check	4-14
Care of Seat Belts	4-14
Child Safety	4-20
Footrest Adjustment	4-23

5. Driving

Winter Driving	5-2
Running-in	5-2
Brakes	5-3
Anti-lock Braking System (ABS plus)	5-3
Touring	5-5

6. Climate Control

Control Panel	6-1
General Information	6-1
System Operation and Button Functions	6-2
Operating Tips	6-5
Air Distribution	6-5
System Fault Display	6-5

7. Interior Features

Sun Visors and Vanity Mirrors	7-1
Sunglasses Stowage Compartment	7-3
Glove Compartment	7-3
Centre Console Armrest	7-3
Cupholder (where fitted)	7-3
Ashtray and Cigar Lighter	7-3

8. Exterior Features

Power-Operated Convertible Top	8-3
Convertible Top Cover	8-4

A comprehensive index is located at the back of this Handbook.

Contents

General Information

Details of the vehicle warranty are given in the 'Total Care Book' (United Kingdom) and 'Service Record and Warranty Book' (Export markets).

Regular maintenance and servicing is the responsibility of the owner. Jaguar Dealers will be pleased to arrange periodic servicing in accordance with the 'Total Care Book' (United Kingdom) and 'Service Record and Warranty Book' (Export markets).

Regular routine maintenance not only helps to prevent unnecessary 'breakdowns' and inconvenience, but enhances the 'trade in' or resale value of the vehicle.

When left-hand or right-hand is used in the text, this refers to the left-hand side or right-hand side of the vehicle, viewed from the rear.

Mobile/portable telephones



WARNING:

Using a mobile/portable telephone without an exterior antenna is not recommended when driving as the electro-magnetic fields produced can cause malfunctions with the vehicle electronic systems.

Check the laws and regulations on the use of cellular telephones in the areas where you drive. Always obey them. Also, give full attention to driving.

Use hands-free operation (if fitted) and pull off the road and park before making or answering a call if driving conditions so require.

Jaguar Total Care (United Kingdom only)

When you purchase a new Jaguar, or one which is under 3 years old, you have automatic entitlement to the Jaguar Total Care package. A Driver's Card, which has the telephone numbers of the providers of Emergency Assistance, will be sent to you. For full details, please refer to the Total Care Handbook, included with the literature pack.

Jaguar Dealers

Jaguar Dealers are chosen with care. Each is dedicated to providing a Sales, Service and Spare Parts facility of the highest standard.

Jaguar Dealers are provided with full technical support from the factory, with comprehensive training for all their technicians. Dealers' workshops operate to a high standard and have all the necessary tools and equipment essential to maintain or repair Jaguar vehicles. A current list of Dealers is included in the vehicle literature pack.

Jaguar Diagnostic System

Many of the vehicle systems are controlled by complex electronic devices. Specialist equipment is required to trace and rectify faults in the systems and ensure that only faulty components are repaired or replaced.

Caution: Severe damage to the electrical system and electronic components can occur if any attempt is made to diagnose faults in the electrical system using conventional diagnostic equipment (for example, the use of test lamps or low impedance voltmeters). The fitting of any electrical accessory should only be entrusted to a Jaguar Dealer.

1-2 Introduction

Genuine Jaguar Parts and Accessories

Your Jaguar Dealer can supply you with genuine replacement parts and accessories which are fully approved to Jaguar's original equipment specification. This will ensure that the safety and performance of your vehicle is maintained for your complete peace of mind.

Please note that fitment of non-genuine parts may invalidate the vehicle warranty if a subsequent fault occurs due to fitting sub-standard replacement parts or accessories.

Jaguar Parts Distribution Service

Jaguar Dealers stock a large number of parts to keep your vehicle maintained and back on the road as quickly as possible. Their service is backed-up by Jaguar's central parts warehouse in Coventry, England, providing next day delivery to most of Europe's Dealers and world-wide within two to three days.

Accessories

A full range of Jaguar Engineering approved accessories including safety, stowage, touring, leisure and lifestyle products are just some of those available from your Jaguar Dealership.

Please ask your Jaguar Dealer for an up-to-date brochure so you can select your requirements from the latest range.

Locking Wheel Nuts

In certain markets vehicles are fitted with locking wheel nuts as standard. See **Wheel Changing and Jacking** in SECTION 4 of the Vehicle Care Handbook.

For other vehicles, locking wheel nuts are available as an accessory. These may vary from the type of locking wheel nut fitted as standard.

After fitting, wheel re-balancing may be necessary and subsequently the locking nut must always be fitted in the same position.

Vehicle Literature Packs

The vehicle literature is in two separate packs within the vehicle.

Glove Compartment Literature Pack

This pack is in the passenger's glove compartment and comprises the following:

Driver's Handbook.
Audio Systems Handbook.
Quick Reference Guide.
Total Care Book (United Kingdom only).
Mondial Book (Certain European markets).

Luggage Compartment Literature Pack

This pack is in the luggage compartment and comprises the following:

Vehicle Care Handbook.
Service Record and Warranty Book (not United Kingdom).
Navigation Handbook (when the Navigation System is fitted).

Fuel

See **Fuel Tank Filling** on page 4-12 and also **Fuel Requirements** in SECTION 6 of the Vehicle Care Handbook.

Electrical Accessories

The fitting of any electrical accessory **should only** be entrusted to a Jaguar Dealer. See **Electrical Accessories** in SECTION 7 of the Vehicle Care Handbook. This information must be observed before fitting any accessories.

Regular Checks

In the interests of safety and reliability, it is advisable to carry out checks at regular intervals, i.e. daily, weekly and monthly. Always check the vehicle thoroughly before starting on a long journey.

See **Regular Checks** in SECTION 3 of the Vehicle Care Handbook.

Emergency Starting

Vehicles with automatic transmissions cannot be tow started. See **Emergency Starting** in SECTION 4 of the Vehicle Care Handbook.

Window Marking

A worthwhile precaution is to have the vehicle registration number etched into each window glass by a Jaguar Dealer.

Safety Precautions



WARNING:

1. Many liquids and other substances used in vehicles are **poisonous** and should never be consumed and must be kept away from open wounds. These substances include anti-freeze, brake fluid, fuel, windscreen washer additives, lubricants and various adhesives.
2. The presence of any unusual fumes (e.g. petrol or exhaust fumes) in the passenger compartment and/or luggage compartment should be corrected immediately by a Jaguar Dealer. If you must drive under these conditions do so only with all windows fully open.
3. Any modifications to the fuel system not specifically designed for this Jaguar are prohibited. Such modifications in some circumstances could result in a fire. All service actions must be entrusted to a Jaguar Dealer.
4. Alterations to the electrical system, including the fitting of accessories not designed for this Jaguar, will cause damage to the electrical circuits and systems. In some circumstances this could result in a malfunction or fire. All accessory work should be entrusted to a Jaguar Dealer.
5. No attempt should be made to repair a fuse that has blown. Always install a fuse of the correct amperage (see Fuse Ratings and Circuits in SECTION 4 of the Vehicle Care Handbook). Failure to comply with the above may cause a fire hazard or serious damage elsewhere in the electrical circuit.

1-4 Introduction

Take particular note of **WARNINGS** and **Cautions** given throughout this handbook.



WARNING:

Procedures which must be followed precisely to help avoid the risk of personal injury.

Caution: Procedures which must be followed precisely to reduce the possibility of damage to the vehicle and resultant risk of personal injury or inconvenience.

Warning symbols on the vehicle

On encountering the warning triangle or open book symbol on the vehicle, it is important that you consult the relevant section of this handbook and the Vehicle Care Handbook before touching this part of the vehicle or attempting adjustments of any kind.



Safety, Warning and Caution Labels

Note: Do not remove any safety, caution or warning labels from the vehicle.

Braking System (A)

The brake fluid caution symbol is moulded into the master cylinder filler cap.

Brake system warning information is moulded into the master cylinder reservoir and states:

WARNING – CLEAN FILLER CAP BEFORE REMOVING. USE ONLY JAGUAR SUPER DOT 4 BRAKE FLUID FROM A SEALED CONTAINER.

Power Steering System (B)

The label is located on the reservoir filler cap and states:

WARNING.


See **Checking and Replenishment** in SECTION 3 of the Vehicle Care Handbook for information on topping up the power steering system.

Cooling System (C)

The header tank label is located on the filler cap and states:

WARNING – DO NOT OPEN WHEN HOT.

Introduction 1-5



Rotating Components (D)

A label is located on the fan shroud and states:

WARNING – ROTATING COMPONENTS – KEEP CLEAR.

Climate Control System (E)

The label located under the bonnet on the left-hand side states:

CAUTION – System pressurised with HFC Refrigerant 134a.
System to be serviced by qualified personnel.

Warning and Information Messages


Warning and information messages are displayed on the message centre which is located within the speedometer.

As well as odometer and trip computer information, status and warning messages may be displayed (along with a red or amber priority indicator to show the type of message), to alert the driver to a situation or vehicle status which may require attention.

Throughout the Handbook, references to messages are made as shown in the example below:

Message: **Bonnet Open** Priority Indicator: **Red**

1-6 Introduction



- A – Gross vehicle weight.
B – Maximum permitted front axle loading.
C – Maximum permitted rear axle loading.

Vehicle Identification

Vehicle Identification Label

It is essential that the Vehicle Identification Number is quoted in all correspondence and when ordering parts.

This number is on a label located on the left-hand door post above the door striker plate. The number is also on a plate visible through the windscreen.

Date of Manufacture Information (Australia only)

Date of manufacture, hereinafter called the 'Build Date', is the calendar month and year in which the body shell and powertrain sub-assemblies are conjoined and the vehicle is driven from the production line.

The vehicle has its 'Build Date' displayed on a metal plate located at the top of the battery tray in the luggage compartment.

Engine Number

V8: Stamped on a raised pad on the front of the engine block near the thermostat housing.

Automatic Transmission Number

The number is located on the left-hand side of the automatic transmission casing.

Introduction

Security Design Features

The security system has been designed for:

- Prevention of theft of the vehicle.
- Prevention of theft of items from the vehicle.
- Rapid recovery of the vehicle.
- Personal security.

The security system is integrated with the electronics and engine management systems making it far more difficult for a thief to penetrate and prevents engine starting unless the correct ignition key is used.

Standard alarm features cover the perimeter sensing of bonnet, doors and luggage compartment.

Passive arming, the automatic alarm system, can be programmed by a Jaguar Dealer. This ensures that the security system arms itself 30 seconds after the doors, bonnet and luggage compartment are closed following removal of the key from the ignition switch.

Note: Passive arming does not lock the doors.

Vehicle Security

Always remove the ignition key and close and lock the doors when leaving your vehicle unattended, even in your garage or driveway.

At night, try to park in a well lit area as this will discourage intruders and thieves.

Security of Keys and Key-ring Transmitters

It is important to keep your keys and key-ring transmitters in safe places at all times. Leaving them in conspicuous places is an invitation for a thief to steal them and, consequently, your car or belongings. Keep them as secure as you would your wallet or purse, both at home and away. Do not leave the key number tag with the keys, detach the number tag and keep it in a safe place.

For increased security, replacement keys are only obtainable from a Jaguar Dealer who will ask for proof of vehicle ownership before the key can be ordered from Jaguar Cars Ltd. A log of all enquiries for replacement keys is kept by Dealers and notified to Jaguar Cars Ltd.

Note: Legislation requires that the United Kingdom and European markets no longer have the audible sounds when arming and disarming the vehicle.

2-2 Security

Key Identification and Locks

Key numbers are recorded on plastic tags which are attached to each key. These numbered tags must be detached and kept in a secure place so that correct replacement keys can be obtained.

A set of three keys is supplied with the vehicle; two black-headed keys (one as a spare) and one green-headed key.


The black-headed keys will lock and unlock the steering column lock/ignition switch, the doors, and the luggage and glove compartments.

The green-headed key is a 'valet' key and must only be used when the vehicle is to be driven and parked by an attendant.



WARNING:

The door windows lower and raise automatically when the door is opened and closed. Keep fingers away from the windows when closing the door. Do not close the door by placing your fingers on top of the glass.



Key Operation

Door locking/unlocking using a key

Locking

Notes:

1. The security system will not arm if a key is in the ignition switch or if a protected entry is open. Ensure that the keys and the key-ring transmitter are removed from the vehicle before locking the doors, and that all doors, the luggage compartment and the bonnet are closed.
2. Remove the convertible top cover (if fitted) before closing the top.

The doors and luggage compartment can be locked or unlocked simultaneously by operating the driver's door lock.

To lock and set alarm (perimeter only)

Turn key towards the front of the vehicle and release. The direction indicators will flash once and, except for the United Kingdom and Europe, a sound will be heard.

This will lock the driver and passenger doors, the luggage compartment and set the alarm system.

Hold the key in the 'Lock' position to close all windows (and the convertible top, if fitted).

Global Locking



WARNING:

When using the 'all close' feature ensure that all occupants are kept clear of the windows and the convertible top.

Turn the key towards the front of the vehicle. Hold in this position and the vehicle alarm system will arm, the windows (and convertible top, if fitted), will close and the doors and luggage compartment will be locked.

To deadlock, and set the alarm (this includes perimeter, and when fitted, tilt sensing or glass break sensing) starting from vehicle unlocked and disarmed.



WARNING:

When the vehicle is deadlocked the doors cannot be opened, either from inside or outside the vehicle, except with the correct key or key-ring transmitter. Breaking a window will not allow a thief access by opening a door. Therefore, deadlocking should not be used when persons are inside the vehicle as they will not be able to vacate, or be released from the vehicle if an emergency arises.

Note: It will not be possible to deadlock the vehicle under the following conditions.

- If any door is open.
- If a key is in the ignition switch.
- If the inertia switch has tripped.

Turn key towards the rear of the vehicle and then towards the front within 3 seconds.

This deadlocks all doors, locks the luggage compartment and sets the alarm system. Once deadlocking is completed, the direction indicators will flash once and (except for United Kingdom and Europe) an audible signal will be heard. This is then followed by a long flash of the direction indicators and a longer audible signal.

Hold the key in the 'Lock' position to close all windows (and sports car convertible top, if fitted).

2-4 Security

Unlocking

To unlock and disarm alarm system (United Kingdom and Europe only)

Turn the key towards the rear of the vehicle and release. This unlocks all doors and the luggage compartment and turns on the interior lights for 2 minutes at $\frac{3}{4}$ brightness. The direction indicators give two flashes as unlocking takes place.

When the vehicle is unlocked in this manner, a ticking sound will be heard when a door is opened. This is a warning to indicate that the vehicle alarm will activate after 7 seconds if the security system is not disarmed with either the key-ring transmitter or by switching the ignition key to position 'II',

Note: Unlocking with the key does not disarm the security system, this provides extra protection against thieves.

With the vehicle disarmed, hold the key in the 'Unlock' position to open all windows and the sports car convertible top, if fitted.

To unlock and disarm alarm system (All markets except United Kingdom and Europe)

Turn key towards the rear of the vehicle and release.

This unlocks all doors, luggage compartment, disarms the alarm system (if fitted), and turns on the interior lights for 2 minutes at $\frac{3}{4}$ brightness. At the same time, the direction indicators will flash twice and two signals will be heard.

Hold the key in the 'Unlock' position to open all windows (and convertible top, if fitted). If the vehicle is fitted with an alarm system, opening is only possible with the vehicle disarmed.

Global Unlocking with Vehicle Armed

First disarm the vehicle with either the key or the transmitter. Put the key into the door lock and hold in the unlock position to open all windows (and the convertible top, if fitted).

Global Unlocking with Vehicle Disarmed

Turn the key to unlock the vehicle and hold in this position to open the windows and the convertible top, if fitted.

Door Locking System (green-headed 'Valet' key)

Before locking the vehicle and handing the green-headed 'valet' key to a parking attendant, press the valet switch on the driver's knee bolster to inhibit the luggage compartment remote release switch. The vehicle can then be parked by an attendant who can lock the vehicle after parking, but cannot open the luggage compartment. The luggage compartment can then only be unlocked with the black-headed key or the key-ring transmitter.

Note: Do not use the green-headed valet key for normal driving. Once isolated from the remote release switch, the luggage compartment cannot be opened with this key.

Key-ring Transmitter

The Security System is controlled remotely by a radio frequency, battery-operated key-ring transmitter. The transmitter uses a random encrypted fixed and rolling code each time the system is used. This provides billions of combinations and ensures that the code cannot be copied.

Each of the two transmitters supplied is designed to be attached to a driver's key-ring.

The key-ring transmitter is activated by pointing it towards the vehicle and pressing one of the four operating buttons.


- A. Locks and arms the vehicle.
- B. Unlocks and disarms the vehicle.
- C. One press switches on headlamps for 25 seconds. Three presses starts the Panic Alarm.
- D. Releases luggage compartment lock.

Care of Key-ring Transmitters

The key-ring transmitters must be treated with care and not exposed to extremes of heat, dust, humidity or be in contact with fluids. The batteries are the only serviceable part.

Key-ring Transmitter Loss

If a transmitter is lost or stolen it is advisable to contact your Dealer, without delay, to have the remaining transmitter re-programmed to prevent anyone using the lost transmitter. A new key-ring transmitter can be obtained from your Jaguar Dealer, who will ask for proof of vehicle ownership.



Key-ring Transmitter Operation

The key-ring transmitter will not operate if the key is in the ignition.

The security system will not arm if the key is in the ignition switch or if any protected entry is open.

Caution: The key-ring transmitter may suffer interference from other legal users of this radio frequency band, such as radio amateurs, medical equipment, remote controls or alarm systems. To lock or unlock the vehicle either use a key or operate the key-ring transmitter as close to the security antenna on the rear screen as possible.

2-6 Security

Key-ring Transmitter Battery Renewal

To ensure that the key-ring transmitter operates at its full capacity, use CR 2016 batteries. When the batteries need renewal there will be a significant decrease in the effective range of the key-ring transmitter.

Caution: To avoid disrupting the coding of the key-ring transmitter during battery renewal, the operating buttons must not be pressed. If the code is disrupted, it will be necessary to have your Jaguar Dealer re-programme the key-ring transmitters.

To renew the batteries, insert a slim blade into the gap in the casing and prise apart, exposing the twin-disc battery cells. Fit two new cells with the sides marked with the positive symbol (+) downwards into the battery receptacle. Refit the battery cover and click into place with thumb pressure.



Key-ring Transmitter Operation – Button Functions

Button A (Locks and arms)


First press (if vehicle is unlocked and disarmed): Locks all doors, luggage compartment and sets the alarm system. The direction indicators will flash once whilst locking and arming occurs. For markets other than the United Kingdom and Europe a single sound will also be heard. The red security system warning light in the gear selector panel will start to flash and will continue flashing while the vehicle is armed.

Second press (within 3 seconds of first press): Deadlocks all doors and sets the alarm system. Once deadlocking is completed one signal will be heard and the direction indicators will give one long flash.

Deadlocking should not be used when persons or animals are inside the vehicle.

Button B (Unlocks and disarms)

One press (if locked and armed): Unlocks all doors and the luggage compartment. Disarms security system alarm and switches on interior lights for 2 minutes at $\frac{3}{4}$ brightness. It also cancels the luggage compartment valet lock-out, if set. The direction indicators will flash twice and, except for the United Kingdom and Europe, two sounds will be heard as the vehicle is unlocked and disarmed.



Button C

One press: Switches on headlamps. The headlamps will remain on for 25 seconds, or until the key is inserted in the ignition switch and turned to position 'II', or if the button is pressed again.

Three presses within 3 seconds: Starts Panic Alarm (where fitted).

Button D

One press: Releases luggage compartment lock.

2-8 Security

Luggage Compartment

The luggage compartment is locked and unlocked electrically in conjunction with the doors. It can also be unlocked by the unlock button on the key-ring transmitter, the remote release switch on the fascia and the black-headed key.

Unlocking Using the Key-ring Transmitter (A)

To operate: Press the unlock button.

Luggage Compartment Remote Release Switch (B)

To operate: Press the switch to release the luggage compartment lid lock.

Luggage Compartment Remote Release 'Valet' Switch (C)

The 'valet' switch is used to inhibit the remote release switch to ensure the security of the luggage compartment.


When the 'valet' switch is pressed, the luggage compartment locks and can then only be unlocked with the black-headed key or by pressing the unlock button on the key-ring transmitter.


Unlocking Using the Black-headed Key (D)

To unlock the luggage compartment when the doors are locked: Ensure the security system is disarmed before unlocking using the black-headed key. Insert the key and turn through 90° clockwise, return the key to the vertical position to remove. The luggage compartment is illuminated by two lights when the lid is raised.

Note: The green-headed 'valet' key will not unlock the luggage compartment.

The luggage compartment locks automatically when the lid is closed.





Interior Door Lock Operation

To lock: Press the door release lever inwards to lock both doors and luggage compartment.

Drive-away Door Locking (All markets except Japan):

This feature is an additional occupant safeguard which locks all the doors and luggage compartment if they are unlocked when the gear selector is moved out of the 'P' or 'N' position. For this feature to operate, the ignition switch must be in position 'II', and all doors and the luggage compartment lid closed.

To unlock: Pull the door release lever.

2-10 Security

Alarms and Audible Signals

Note: In certain markets, legislation prohibits the use of alarms and audible signals. In such cases, the sound source has been removed from the system.

Full Alarm

Once armed, any of the following circumstances will create a full alarm state:

- Opening a door with a key (for the United Kingdom and Europe only, a ticking will be heard and the alarm will be delayed for 7 seconds).
- Opening the luggage compartment with the key but with a 7 seconds delay (except United Kingdom and Europe when the alarm sounds immediately).
- Opening the bonnet.
- Breaking any window or windscreen (if glass break sensing is fitted).
- If an invalid key is inserted into the ignition switch and turned to position 'I' or 'II'.
- Lifting or tilting the vehicle, for example, an unauthorised towing away attempt (if a tilt sensor is fitted).
- Pressing headlamp button on key-ring transmitter three times within 3 seconds produces the Panic Alarm (if fitted).

Error Tone

The sounder gives a short, high-pitched tone whenever one of the following conditions is present:

- If any door is open when an attempt to 'arm' the security system is made.
- The luggage compartment or the bonnet is not properly closed when an attempt to 'arm' the security system is made.
- If a key is in the ignition switch when a transmitter button is pressed.
- If there is an electrical failure within the:
 glass break sensing system (if fitted), or
 tilt sensing systems (if fitted).
and an attempt to 'disarm' the security system is made.

Audible Signals

An audible signal will sound when:

- The vehicle is deadlocked.
- The 'Valet' switch is pressed with the luggage compartment closed or when in Valet mode and the interior luggage compartment release button is pressed.
- A door is opened if the vehicle has been actively armed (United Kingdom and Europe only). This mode can be cancelled by disarming the security system using the key-ring transmitter or by switching the ignition to position 'I'.

Security System Features

Valet Key Locking

Before locking the vehicle and handing the green-headed 'valet' key to a parking attendant, press the valet switch to inhibit the luggage compartment interior release switch. The vehicle can then be parked by an attendant who can lock the vehicle after parking, but cannot open the luggage compartment. The luggage compartment can then only be unlocked with the black-headed key or the key-ring transmitter.

Panic Alarm (Dealer option)

When in or near the vehicle, the alarm can be set off to deter a would-be offender. This feature will also unlock the doors. For this feature to operate, the key must **not** be in the ignition switch.

Pressing the headlamp button on the key-ring transmitter three times within 3 seconds will activate the 'Panic Alarm'.

The Panic Alarm will sound for the normal full alarm period. The alarm is stopped by turning the ignition key to position 'I' or 'II'.

The key-ring transmitter cannot be used to cancel the Panic Alarm, this prevents unauthorised use.

Remote Headlamp Convenience

By pressing the key-ring transmitter button with the dipped headlamp symbol once, the headlamps will come on for 25 seconds, unless the headlamp button is pressed again, or if the key is inserted in the ignition switch and turned to position 'II'.

Passive Arming (Dealer option)

Passive arming will not lock the doors, it only arms the security alarm system.

Passive arming, if preset by a Jaguar Dealer, will automatically arm the vehicle alarm system 30 seconds after the last protected entry, (door, luggage compartment or bonnet) is closed following the key being removed from the ignition switch.

When passive arming occurs the direction indicators will flash once and, except for the United Kingdom and Europe, a single tone will be heard. The red security light on the gear selector surround will start to flash and will continue for as long as the vehicle is armed.

Opening a protected entry causes a warning sound which continues for 15 seconds before the vehicle goes into the full alarm state.

If the system has been armed passively it can be disarmed by either the key-ring transmitter, or by switching the ignition to position 'I'.

Note: The security system will not passively arm if a key is in the ignition switch or if any protected entry is open.

2-12 Security

Perimeter Sensing

Perimeter sensing is put into operation every time the vehicle is armed. This feature sounds the alarm if any unauthorised opening of doors or luggage compartment or bonnet occurs.

Glass Break Sensing (if fitted)

A sensor, programmed to activate when glass is broken, is activated every time the vehicle is armed. If an attempted intrusion into the vehicle by glass breaking takes place the alarm will sound.

Battery Tampering Alarm and Restart Procedure

This feature prevents the security system being by-passed by battery disconnection.

If the battery is disconnected when the security system is either armed, disarmed or in the full alarm state, the security system will automatically resume the vehicle state before disconnection when the battery is reconnected.

Tilt Sensing Protection (if fitted)

This feature protects against unauthorised towing away or jacking up. As soon as an attempt is made to tilt the vehicle, to tow away or jack the vehicle up, if the system is 'armed', the security system will enter the full alarm state.

Note: If the tilt sensor operates the alarm when the vehicle is being transported by road, rail or sea, do not unlock the vehicle, the alarm will sound for a limited time only.

Battery Back-up Sounder

On certain markets a separate battery back-up sounder is fitted. This device will sound an alarm if the vehicle battery or the sounder is disconnected when the security system is armed.

Caution: Do not disconnect the vehicle battery or sounder if the security system is armed as this will cause the alarm to sound. To switch off the alarm, reconnect the vehicle battery or sounder and disarm the security system in the usual manner.

Engine Immobilisation

For some markets, the ignition key has an engine immobilising device in the plastic head. Engine immobilisation occurs automatically when the ignition key is turned to position '0'.

Caution: Should the ignition key be lost, a new key can be obtained and programmed to the vehicle by a Jaguar Dealer who will ask for proof of vehicle ownership. It is advisable to notify a Dealer as soon as a key is lost or stolen and have the remaining key(s) reprogrammed. This will then prevent the lost or stolen key from being used to start the engine.

Radio Frequency Approval

This applies only to the following countries:

- B – Belgium
- CH – Switzerland
- E – Spain
- GB – Great Britain
- GR – Greece
- H – Hungary
- IRL – Ireland
- N – Norway
- P – Portugal
- PL – Poland
- S – Sweden
- SF – Finland

LPD – Low Power Device

	RXREJ	TXREJ
(SF) LPD FI96080042	(GR) LPD	(H) LPD
(N) LPD NO96000255-R	(PL)	(P) LPD ICP-029TC-96
(S) LPD Ue 960159	(GB) LPD MPT 1340 W.T. LICENCE EXEMPT	(B) LPD RTT/D/X1264
(CH) LPD BAKOM 96.0384.K.P.	(E) LPD <hr/> (E) CEPT LPD	(IRL) LPD TRA24/5/73/3




2-14 Security

Radio Frequency Approval (continued)


This applies only to the following countries:

- D - Germany
- DK - Denmark
- F - France
- I - Italy
- L - Luxembourg
- NL - Netherlands

LPD - Low Power Device

RXREJ		TXREJ
<p>(L) LPD</p> <p>L2432/ 10094-01G</p>	<p>(NL) LPD</p> <p>rcd. NL</p> <p>HDTP / RDR / 340021</p>	<p>(I) LPD</p> <p>DG PGF/4/2/ 03/338547/ FO/0001961</p>
<p>(D) RXREJ</p> <p> B G127 Z T 272H</p> <p>LPD-D</p>	<p>(D) TXREJ</p> <p> B G127 Z T 273H</p> <p>CERT LPD-D</p>	
<p> AGREÉ DGPT Ministère chargé des Télécommunications</p>		<p>agr. 96 0257 PPLD date 21.06.1996 pres. Jaguar Cars</p> <p>Connectable au réseau public français</p>
		<p>(DK) LPD</p> <p>Tilladelsesnummer ALR 9639 Telestyrelsen</p>

Instruments - Controls 3-1



Instruments

Tachometer (A)

The tachometer indicates engine speed in revolutions per minute and is calibrated in increments of 500 extending to 7500 rev/min.

Speedometer (B)

Speed indication is in miles and kilometres per hour, or kilometres per hour according to the vehicle's market specification.

Odometer (C)

Records the total distance covered by the vehicle.

Fuel Level Gauge (D)

Indicates the amount of fuel in the tank. The gauge works only with the ignition ON and in position 'II'.

A warning light indicates when the remaining fuel has fallen to approximately 10 litres (2.2 gallons).

Engine Coolant Temperature (E)

Indicates the temperature of the engine coolant.

Drive at moderate road and engine speeds until normal operating temperature is reached. This is indicated when the pointer is between the blue (cold) segment and the red (hot) segment.

The engine operating temperature will vary with changes in weather and engine load. The engine temperature may rise in some circumstances, such as:

- Idling for long periods in slow moving traffic.
- Driving up a long hill in hot weather.
- Driving slowly or stopping after driving at high speed.

Should the pointer move into the red segment (H), stop the vehicle as soon as it is safely possible and allow the engine to cool.


Switching off the climate control system may assist engine cooling.



WARNING:

Do not remove the pressure cap from the coolant expansion tank filler while the engine is hot.

3-2 Instruments - Controls



The following gauges are situated on the fascia panel above the centre console. If a navigation system is fitted the gauges will no longer be part of the fascia and tell-tale lights on the instrument cluster will give indication of battery and oil pressure status.

Oil Pressure Gauge (F)

Indicates the engine oil pressure, not the level of oil in the engine.

Caution: If the needle falls into the Red segment, stop the vehicle as soon as it is safely possible and investigate the cause.

Clock (G)

The analogue clock can be adjusted by pressing the (+) and (-) buttons on the front of the dial. Pressing and holding either button will increase the rate of hand movement forwards or backwards as required.

If a navigation system is fitted, the clock is displayed on the navigation screen when the system is switched on.


Battery Condition Indicator (H)

Indicates the charge condition of the battery.

With the ignition in position 'II' and the engine not running, the pointer should be between 9 and 13 volts. If it is in the low red sector, the battery and/or charging system requires attention.

When the engine is running, above idle speed, the pointer should be between 13 and 17 volts. If the pointer is in the high red sector, the charging rate is too high and the cause must be investigated

Instruments - Controls 3-3




Warning Lights

Thirteen warning lights (fourteen in Middle East markets) are arranged within the dials of the two instrument clusters.




RED warning lights are for primary warnings. AMBER warning lights are for secondary warnings. Lighting and direction indicator warning lights are BLUE or GREEN.

A bulb check cycle is initiated when the ignition is switched ON and lasts for 3 to 4 seconds. The CHECK ENG warning light stays on until the engine is started. If any warning light remains on, investigate the cause before driving.






When activated, some warning lights have associated messages displayed on the message centre, as shown in the table on the next page.






3-4 Instruments - Controls

Warning Light	Message	Priority Indicator	Meaning
 Check Engine	None	None	Lights up when the ignition is switched ON and remains on until the engine is started.
 Anti-lock Braking (ABS)	None	None	<p>Lights up if a fault has been detected in the ABS system. The brake system will continue to function normally but without ABS braking.</p> <p>Should the light come on or stay on after the bulb check cycle, stop the vehicle at the first opportunity, turn the engine OFF and then restart.</p> <p>If the warning light comes on again, consult a Jaguar Dealer immediately.</p> <p>The vehicle may be driven to a Jaguar Dealer if the ABS warning light is ON, but must not be driven if the brake warning light is ON</p>
 Seat Belt	None	None	<p>Lights up when the ignition is ON and the driver's seat belt is not fastened.</p> <p>Taiwan and Middle East Markets Only</p> <p>Lights up for 6 seconds when the ignition is switched ON and the driver's seat belt is not fastened. An audible warning sounds for 6 seconds.</p> <p>Note: Ensure seat belts are fastened before driving. If the warning light stays ON with the seat belt fastened, report the fault to a Jaguar Dealer. It is safe to drive the vehicle with the light ON, provided that the seat belts are properly fastened.</p>






Instruments - Controls 3-5

Warning Light	Message	Priority Indicator	Meaning
 Airbag	None	None	<p>When the ignition switch is turned to position 'II', the warning light comes ON for 5 seconds.</p> <p>If the airbag system develops a fault, the warning light will come ON and remain on until the fault has been diagnosed and cleared.</p> <p>Report the fault to a Jaguar Dealer immediately. It is safe to drive the vehicle; however, in an accident the airbags may not operate.</p>
 Headlamp Main Beam	None	None	<p>Lights up when the headlamps are on main beam.</p>
 Brake (UK Market)	LOW BRAKE FLUID	Red	<p>Lights up when the ignition is ON if the handbrake is applied and/or the brake fluid is low.</p> <p>If the light is ON with the handbrake NOT applied, low brake fluid is indicated. In this case, loss of braking assistance in either or both brake circuits may be imminent.</p> <p> WARNING: DO NOT drive the vehicle until the fault is rectified. Consult a Jaguar Dealer immediately.</p>
 Brake (Other Markets)			

3-6 Instruments - Controls

Warning Light	Message	Priority Indicator	Meaning
 <p>Sidelights</p>	None	None	Lights up when the sidelights are switched ON.
 <p>Direction Indicator Tell-tale (left and right)</p>	None	None	<p>The appropriate indicator tell-tale will flash when the column switch is moved up or down to signal a right or left-hand turn.</p> <p>If a direction indicator fails, the tell-tale will flash and the audible warning will sound at twice normal rate when that indicator is selected. Fit a new bulb immediately. See Bulb Renewal in SECTION 5 of the Vehicle Care Handbook.</p> <p>Hazard Warning Indicators</p> <p>When the hazard warning switch is selected, both direction indicator tell-tales will flash, simultaneously with all direction indicators, and repeaters (where fitted).</p>
 <p>Overspeed Warning Indicator (Middle East markets only)</p>	None	None	Lights up if the vehicle speed exceeds 120 km/h (75 mph).

Instruments - Controls 3-7

Warning Light	Message	Priority Indicator	Meaning
 Low Fuel Level	None	None	Lights up to indicate low fuel level. This warning light is additional to the fuel level gauge and will come ON when the fuel has fallen to approximately 10 litres (2.2 gallons).
 Low Oil Pressure	LOW OIL PRESSURE	Red	<p>Lights up when the ignition switch is in position 'II' and should go out when the engine is running. If the light is ON when the engine is running, loss of oil pressure is indicated. Stop the engine immediately and investigate the cause. Do not restart until the fault has been rectified.</p> <p>First check the engine oil level. See Checking and Replenishment in SECTION 3 of the Vehicle Care Handbook.</p>
 Ignition (Charge Warning)	BATTERY NOT CHARGING	Red	<p>Lights up when the ignition switch is in position 'II' and should go out when the engine is running. If the light stays ON when the engine is running it indicates either high or low battery voltage or that the alternator is faulty.</p> <p>Stop the engine and investigate the cause.</p>
 High Coolant Temperature	None	None	<p>Lights up if the engine coolant temperature becomes too high (gauge pointer in the red segment). It is unsafe to run the engine with the coolant temperature overheated.</p> <p>If the light comes ON, stop the vehicle and switch the engine OFF. Allow the engine to cool. Report the fault to a Jaguar Dealer.</p> <p> WARNING: Do not attempt to remove the pressure cap from the coolant expansion tank until the engine is cool.</p>

3-8 Instruments - Controls

Message Centre

Driver information, messages, and data are displayed on the message centre display panel situated within the speedometer.

The message centre has three functions. These are:

1. **Odometer:** Displays the total distance covered by the vehicle.
2. **Trip Computer:** Displays information on the vehicle's average speed, fuel usage and range.
3. **Warning and Information Messages:** Displays status messages or warning messages if system faults are detected.

Selecting Message Centre Functions



Message centre functions are selected by repeatedly pressing the trip function button on the left-hand column switch. The first press will switch from the odometer reading to the trip computer. Further presses will cycle through the trip computer data in sequence, until the odometer reading is displayed again.

Note: Messages take priority over the odometer reading or trip computer data and, if active, will be displayed when the ignition is switched ON.

Odometer

When the ignition is switched ON the message centre displays the odometer reading. The odometer will also be displayed if the ignition is in position '0' and the interior lights are ON.

The odometer reading is displayed in either kilometres or miles, depending on the vehicle's market specification. A vehicle with a speedometer marked in km/h gives the odometer reading in kilometres.



Instruments - Controls 3-9

Warning and Information Messages

The message centre will display warning or information messages to the driver when the ignition is in position 'II'.

Most messages, when displayed, have an associated priority indicator light above the display which will come on to indicate the message priority:

Red light: Priority message **Amber light:** Secondary message.



WARNING:

If a red warning light is displayed, stop the vehicle, or take appropriate action, as soon as possible.

A priority message must be investigated immediately by the driver or a Jaguar Dealer.

If more than one message is active, each is displayed in turn for 2 seconds in order of priority.

Clearing Messages

Messages can be hidden by pressing CLEAR on the trip computer switchpack. One press will hide one message. Once all messages have been hidden, the display will show trip data, a further press will display the odometer reading. If CLEAR is pressed again all active messages will be 're-displayed'. Repeatedly pressing the CLEAR button will cycle through the trip odometer and message modes.

Hidden messages reappear after the ignition is switched OFF and ON again, if the fault remains.

If a fault occurs when in trip computer or odometer mode, the relevant message will be displayed immediately.

If a trip computer function is selected by pressing the function

button while messages are displayed, the trip data will be displayed for 10 seconds, then the message will reappear.

Language Selection

To obtain the language selection feature, press and hold the 'ml-km' switch on the trip computer switchpack whilst turning the ignition key to position 'II'. The first language displayed is the one currently selected. The language will be displayed for 10 seconds.

To cycle through the language options, press the 'ml-km' switch repeatedly while the languages are still being displayed.

When the language required is displayed press the 'A/B' switch. The new language will be selected and displayed for a further 2 seconds.

Press CLEAR or start the engine to display the odometer reading. (The odometer reading is automatically displayed after 10 seconds.)

Message Centre Illumination

The message centre is illuminated at all times when the ignition is ON.

The illumination level can be adjusted by the dimmer switch.

3-10 Instruments - Controls

Message	Priority Indicator	Meaning
SYSTEM CHECK	Both	Instruments self check immediately after ignition ON and language selection.
ENGINE STALLED	Red	Engine speed has dropped below 10 rev/min.
ENGINE COOLANT LOW	Red	Check the level in the coolant reservoir. Check temperature gauge often.
DRIVERS DOOR OPEN	Red	Check that the driver's door is closed before driving.
PASSENGERS DOOR OPEN	Red	Check that the passenger's doors are closed before driving.
HOOD NOT LATCHED	Red	Check that the convertible top is closed and locked.
TRACTION CONTROL FAIL	Amber	Report fault to a Jaguar Dealer. The vehicle may still be driven.
ASC	Amber	Traction Control is operating.
FAIL SAFE ENGINE MODE OR RESTRICTED PERFORMANCE	Amber	Loss of power or driveability. Report fault to a Jaguar Dealer. The vehicle may still be driven.
	Red	Loss of power or driveability. Do not drive the vehicle. Report fault to a Jaguar Dealer.
BONNET OPEN	Red	Check that the bonnet is closed securely.
BOOT OPEN	Red	Check that the luggage compartment is closed securely.

Instruments - Controls 3-11

Message	Priority Indicator	Meaning
GEARBOX FAULT	Amber	Transmission defaults to a limp home mode giving reduced operation. Drive with caution. Report fault to a Jaguar Dealer immediately.
HIGH GEARBOX TEMPERATURE	Amber	Transmission defaults to 'hot mode' to aid cooling. The vehicle may still be driven.
HANDBRAKE ON	Red	Check that the handbrake is fully OFF.
CHECK REAR LIGHTS	Amber	Rear bulb failure.
WASHER FLUID LOW	Amber	Check the fluid in the windscreen washer reservoir.
SUSPENSION FAULT	Amber	Adaptive damping failure (where fitted). Report fault to a Jaguar Dealer. The vehicle may still be driven.
ELECTRICAL FAULT	Amber	Ignition supply fault. Possible reduced electrical operation. Most warning lights will not operate. Report fault to a Jaguar dealer immediately.
VALET MODE	None	Displayed for 3 seconds when the valet mode is activated and if interior luggage compartment release is pressed in valet mode.

3-12 Instruments - Controls

Trip Computer

The computer memory stores data for a journey or series of journeys until it is reset to zero. Two independent memories are available (A and B) to allow two separate journeys to be recorded concurrently, e.g. work usage and evening/weekend usage.

All trip data displayed, apart from 'Range' and 'Instantaneous Fuel Usage' will be prefixed by the letter A or B depending on which trip memory was last selected.

The information is for guidance only, as it can be affected by traffic, road and weather conditions.

To display trip data on the message centre the ignition must be in position 'II'. Press the function button repeatedly to display the data in the following order:

Odometer

Total vehicle distance travelled.

Trip Distance


Distance travelled since the last memory reset. The maximum trip reading is 16090 kilometres (9999.9 miles). The computer will automatically reset to zero if this distance is exceeded.

Range

Distance that the vehicle should travel on the remaining fuel, assuming average speed and fuel consumption stay constant.

Fuel Used

The amount of fuel used since the last memory reset.



Average Fuel

The display shows 'AVE FUEL'. Average fuel consumption since the last memory reset.

Instantaneous Fuel Usage

The display shows 'INST FUEL USAGE'. The 'at the moment' fuel consumption, calculated over a 3 second period and continuously updated.

Average Speed

For the distance travelled since the last memory reset.

Instruments - Controls 3-13

The Trip Computer Switchpack

000

Sets the selected trip to zero.

A/B

Toggles between trip memories A and B, while memory data is being displayed.

ml-km

Selects metric or imperial data display.

CLEAR

The CLEAR button can be used to cycle through: TRIP – ODO – MESSAGES.


Note: The 'A/B' and 'ml-km' buttons are also used for the message centre language selection feature.

Trip Data Display

Warning and Information messages have priority over trip data and, if active, will be displayed when the ignition is ON.

To hide warning messages and display trip data, press the CLEAR button.

Note: If messages are not hidden, trip data can still be selected by using the function button. Trip data will be displayed for 10 seconds before the message is displayed again.



Resetting the Trip Computer

At the start of the journey, or series of journeys, to be recorded, reset the computer memory to zero as follows:

1. Press the trip function button to select a computer function.
The computer will display either trip A or trip B data.
2. Press the A/B switch to select the trip (A or B) to be reset.
3. Press the 000 switch and hold for 3 seconds.

The display will read:

or

A: TRIP RESETTNG

B: TRIP RESETTNG

Then it will reset and display:

or

A: 0.0

B: 0.0

Note: Only the trip displayed (A or B) will be reset.

3-14 Instruments - Controls

Selecting Metric/Imperial Display

Pressing the 'ml-km' switch displays data in metric or imperial units alternately. The units used for computer functions are:

FUEL USED – Litres / Imperial Gallons

AVERAGE FUEL – Litres per 100 km / miles per gallon


INSTANTANEOUS FUEL – Litres per 100 km / miles per gallon

Note: Japanese market only.

Japanese market vehicle data for average fuel consumption is displayed in km per litre or miles per US gallon.

Notes On Using the Trip Computer:

1. 'Range' and 'Instantaneous Fuel Usage' data is independent from the trip computer and cannot be reset. The data is common to both trip memories and is not prefixed by A or B on the display.
2. The trip memory data cannot be reset to zero if either 'Range' or 'Instantaneous Fuel Usage' is displayed.



Instrument Illumination and Dimmer Switch

With the ignition switch in position 'II', the instruments, message centre, climate control and sound system displays will be illuminated. When the exterior lighting is switched ON, the instruments and message centre may be dimmed by means of the dimmer switch. The climate control panel and radio will be illuminated at a low level. If the dimmer switch is set to the 'override' position, the instruments, message centre, climate control and audio systems displays, will be illuminated at maximum brightness. Warning light brightness is not affected by the dimmer switch.

To operate: Rotate the knob to adjust the illumination to the required level. To select 'override', turn the knob fully anti-clockwise.

Automatic Transmission

The five-speed automatic transmission is designed to accommodate different driving styles and automatically adapt shift patterns to suit varying road/driving conditions.

The switch marked 'S' on the 'J' gate surround enables the driver to select either normal 'N' or sport 'S' transmission modes.

In addition to the 'switched' transmission modes ('N' and 'S') the transmission control module will select shift patterns to suit specific conditions. These are:

Cruise Control – When cruise control is operating at set speed the transmission selects a shift pattern to suit cruise control operation.

Traction Control – When traction control is switched ON and the system is activated, the transmission selects a shift pattern to suit traction control conditions.


Gradients – When the vehicle is being driven on roads with uphill gradients, the transmission selects a shift pattern designed to make better use of engine power and aid engine cooling.

Note: Under the conditions described above, the relevant transmission mode will override the 'N' or 'S' modes selected by the driver. When such conditions no longer exist, e.g. Cruise Control switched OFF, the transmission will revert to the shift pattern previously selected by the driver, i.e. 'N' or 'S'.

'J' Gate Selector

The 'J' gate gear selector lever is designed to accommodate two different driving techniques as follows:

1. **Automatic selection.** The right-hand side of the selector gate is less cluttered than a conventional selector.



2. **Manual selection.** The left-hand side of the selector gate may be used for manual selection.

Note: Both sides of the 'J' gate can be used irrespective of the transmission mode, e.g. with 'S' selected the transmission can be operated in full automatic or by manual selection.

Sport Mode

Switch (A) selects either normal or sport (S) mode.

When sport mode is selected the gear shift points are extended to make full use of the engine's power reserves.

To operate: Press the switch (A). The switch lights up to indicate that sport mode has been selected. Press the switch again to cancel sport mode.

3-16 Instruments - Controls

Gear-shift Interlock

A brake pedal/gear-shift interlock system is incorporated in the gear selector mechanism. Once the ignition key has been removed, the gear selector is locked in position 'P'. Also the ignition key cannot be removed from the ignition until the gear selector has been moved to position 'P'.

To move the gear selector from position 'P':

1. Turn the ignition key to position 'II' or start the engine.
2. Press the brake pedal.

To remove the ignition key move the gear selector to Park 'P'.

Gear-shift Interlock Manual Override

In the event of the gear-shift interlock failing to operate, the gear selector can be unlocked from the 'P' position manually as follows:

1. Remove the screw-in plug (B - illustration on page 3-15) using a suitable tool.
2. Insert the ignition key (or similar shaped tool) into the hole.
3. Push the key/tool down gently and hold whilst simultaneously moving the gear selector out of 'P', but not into Reverse.

Caution: Do not move the gear selector fully into Reverse until the ignition key/tool has been removed from the 'J' gate.

4. An audible warning will sound when the gear selector is moved from 'P' provided the ignition is OFF.
5. Remove the ignition key/tool and move the gear selector into Neutral for starting. Refit the plug.

Gear Selector Positions



WARNING:

The handbrake or brake pedal must be applied before selecting forward or reverse drive from a stationary position.

Note:

1. After selecting forward or reverse drive ranges from Neutral or Park, wait briefly for the transmission to engage before accelerating.
2. When in Neutral or Park the engine can only be accelerated to 3000 rev/min (supercharged models only).

P Park – Only use when parking. Apply the handbrake before selecting park.

R Reverse – Do not select if the vehicle is moving forward. The reversing lights come ON automatically with 'R' selected and the ignition switch in position 'II'.

N Neutral – Disconnects the driveline from the engine. Use with the handbrake when stopping temporarily.

D Drive – All five gears are changed automatically as required by the throttle position and road speed.

2, 3, 4 Second, third, fourth – If selected, the transmission operates automatically but will not engage gears higher than the one selected.

Instruments - Controls 3-17

Drive To Fourth

When driving in gear position 'D' with fifth gear engaged, the gear selector can be shifted horizontally across the gate to '4'. Provided that the vehicle's speed is not too great, the transmission will shift down to fourth. Fifth will be inhibited until the gear selector is moved back to 'D'.

Starting and Stopping

The engine cannot be started until the gear selector is in 'N' or 'P'.

When the vehicle is stationary the gear selector may be left in 'D', '2', '3' or '4', unless the vehicle is to be parked. When stopping for traffic lights, junctions etc., apply the handbrake and select 'N'.

Note: When the ignition switch is in position '0', an audible warning will sound for 10 seconds if the gear selector is not in 'P'.

Engine Braking on Downhill Gradients

To achieve appropriate levels of engine braking when driving on roads with long downhill gradients, position '3' or '2' may be selected depending on road and traffic conditions.

When the gear selector is moved from 'D', '4' or '3' down to '2', downshift to second gear will only take place at road speeds below 96 km/h (60 mph).

Reverse Inhibit

Selecting reverse is inhibited when the vehicle is moving forward.

Note: Reverse inhibit will not function in limp home mode.

Kickdown

Kickdown is operated when the accelerator pedal is pressed fully down. Kickdown is used to change to a lower gear in circumstances where rapid acceleration is required, such as when overtaking.

Kickdown causes the transmission to change down to the lowest gear possible to achieve maximum acceleration. The gear engaged depends on the road speed at the time of kickdown. Kickdown provides maximum engine performance.

As well as shifting down, the gear shift points are extended to give greater performance. This mode is in effect for as long as the pedal is pressed fully down.

3-18 Instruments - Controls

Limp Home Mode

In the unlikely event of an electrical or mechanical transmission fault, the transmission will enter limp home mode, which enables the vehicle to be driven to a safe area.

Vehicles with normally aspirated engines will limit the number of gears available. Vehicles with supercharged engines will hold the gear engaged at the time of the fault.

After stopping the vehicle, placing the gear selector in 'P' then selecting 'D':

- supercharged engines - only second gear is engaged.
- normally aspirated engines will limit the number of gears available.
- reverse gear can be selected - all vehicles.

The driver should be aware that in limp home mode the vehicle's performance will be greatly reduced and must take this into account when driving. In this event consult a Jaguar Dealer **immediately**.

Message: **Gearbox Fault** Priority Indicator: **Amber**

Note: For details of vehicle recovery, see **Vehicle Recovery** in SECTION 4 of the Vehicle Care Handbook.

Cruise (Speed) Control (where fitted)

The cruise (speed) control, when activated, maintains a constant road speed without the driver having to use the accelerator.

The system is operated by an ON/OFF master switch (A) mounted in the gear selector surround and four control buttons mounted on the steering wheel. These are:

'SET +': Set speed or accelerate (B)

'-': Decelerate (C)

'RESUME': Resume set speed (D)

'CANCEL': Cancels without erasing memorised speed (E)

Note: The cruise control mode will not operate below speeds of 26 km/h (16 mph).

Setting a Speed



WARNING:

Only use cruise control when conditions are favourable, e.g. straight, dry, open roads with light traffic.



Push the ON/OFF switch. A red warning light on the switch will come ON.

Accelerate as normal until the required speed is reached.

Press the 'SET +' button briefly and the vehicle speed will then be stored in the memory and the system engaged.

The driver can then release the accelerator and the set road speed will be maintained.

Note: Braking will cancel the cruise control function, restoring accelerator control to the driver.



3-20 Instruments - Controls

Changing the Set Speed

There are three ways to change the set speed.

1. Accelerate or brake to the required speed and press the 'SET +' button.
2. Increase or decrease the speed by pressing and holding either the 'SET +' or '-' button. The speed will change gradually until the button is released.
3. Increase or decrease the speed in steps of 2 km/h (1 mph) by briefly pressing the 'SET +' or '-' button. The system will allow a maximum of five increments above or below the set speed.

Resuming a Set Speed

If cruise control is cancelled, e.g. by braking, the original set speed can be resumed, provided the set speed memory is not erased.

Caution:

1. 'RESUME' should only be used if the driver is aware of the set speed and intends to return to it.
2. It is not recommended that a set speed is resumed in gear position '2' or '3', as excessive engine speeds will occur.

If the vehicle is accelerated above the set speed the set speed will be resumed gradually when the accelerator is released.

Braking will cancel the cruise control mode. Pressing 'RESUME' gradually increases speed until the set speed is again reached.

Switching Off Cruise Control

1. Press the CANCEL button (speed memory retained).
2. Push the ON/OFF switch down (OFF) (speed memory erased).

Cruise Control Automatic Switch Off

Cruise control will disengage, but not clear the memory, when:

- a. The CANCEL button is pressed.
- b. The brake pedal is pressed.
- c. Speed falls below 24 km/h (15 mph), or 50% of set speed.
- d. Neutral, Park or Reverse gear positions are selected.
- e. Traction control or stability control is activated.
- f. The set speed is above 144 km/h (90 mph); cruise control will disengage automatically after approximately 20 minutes.

Cruise control will disengage and clear the memory when:

- a. The ON/OFF switch is set to OFF.
- b. The ignition is switched to position '0'.
- c. The handbrake is applied.
- d. Maximum vehicle speed is reached.
- e. The On-board Diagnostic system detects a malfunction. If a fault occurs, the cruise control system will switch OFF and will remain inhibited until the fault is cleared.

Instruments - Controls 3-21

Notes On Using Cruise Control

1. Cruise control operates when the gear selector lever is in position '2', '3' '4' or 'D'.
2. When engaged, the accelerator pedal rests in the raised position. If pressed, pedal load will be noticeably less than normal (non-cruise control) driving, until the point at which acceleration starts, then pedal load will return to normal.

Traction Control

The traction control system will intervene to prevent wheel spin if it is detected by wheel speed sensors. Under these conditions, engine torque is controlled within driver demand and individual wheel braking is applied.

This also improves acceleration, particularly on surfaces with uneven friction, e.g. one wheel on ice the other on tarmac.


Traction Control is always switched ON when the engine is started. The system can be switched OFF by pressing the TRAC OFF switch on the centre console switchpack. The LED in the switch lights up to warn that the system has been switched OFF. If the switch is pressed again the system will switch ON.

Note: If cruise control is engaged it will automatically disengage if Traction Control activates.

If the system is activated a message is displayed and the amber warning light flashes.

A system malfunction is indicated by a message. It is safe to drive the vehicle but the system may not activate under wheel spin conditions. Report the fault to a Jaguar Dealer as soon as possible.

Message: **Traction Control Fail** Priority Indicator: **Amber**



WARNING:

1. The fact that the vehicle is fitted with Traction Control must never allow the driver to be tempted into taking risks which could affect his/her safety or that of other road users. In all cases it remains the driver's responsibility to drive safely according to the prevailing conditions.
2. Traction Control systems cannot overcome the consequences of trying to corner at too high a speed.
3. It is recommended that, if using snow chains, Traction Control should be switched OFF.

3-22 Instruments - Controls

Window Operation

Two switches on the driver's door switchpack control the driver and passenger door windows. The passenger is provided with a switch to control the passenger door window only.

These switches only operate:

1. When the ignition switch is in position 'I' or 'II', or
2. After the ignition has been switched OFF, until a door has been opened.



WARNING:



1. When raising windows ensure all occupants are clear.
2. When leaving the vehicle take the ignition keys to prevent misuse of the window switches by remaining occupants, especially children.
3. Obstruction detection is not available.

Operation

To open: Press and hold the lower part of the switch. Release the switch to stop movement.

To close: Press and hold the upper part of the switch. Release the switch to stop movement.

Note: If the switches are held for longer than 8 seconds, e.g. when attempting to overcome frozen or jammed windows, the window drive will be switched off for a few seconds to protect the window drive motors.



Instruments - Controls 3-23

One-Touch Open Operation

Briefly press and release the lower part of the driver's window switch – the window will fully open. Window travel can be stopped by pressing the switch again.

Automatic Window Drop for Door Opening



WARNING:

The door windows lower partially when the door is opened and raise when it is closed. Do not attempt to close the door by holding on to or pushing against the top of the glass.

The frameless door windows create a seal against the convertible top or the roof seals. If fully raised, the door windows will drop partially when the door release lever is operated; this is to allow easy door opening. When the door is closed the windows rise to the fully closed position.

The doors must not be opened if power for 'automatic window drop' is not available, e.g. with battery disconnected. However, in an emergency the doors can be opened with the windows fully up.

Caution: Do not close the door with the windows fully up as damage to the seals and the glass will occur.

Re-programming Door Windows after Power Disconnection

After battery disconnection or fuse removal, the system must 're-learn' the limits of window travel. This is to ensure correct operation of the automatic window drop facilities.

Re-programming is done with the doors closed and the ignition switch in position 'I' or 'II', as follows:

1. Press and hold the lower part of the switch. When the window is fully lowered, continue to hold the switch for 5 seconds.
2. Press and hold the upper part of the switch. When the window is fully raised continue to hold the switch for 5 seconds.

Carry out this procedure for driver and passenger door windows.

3-24 Instruments - Controls

Rear Quarter Window Operation (Convertibles Only)

The rear quarter windows operate automatically in conjunction with convertible top opening or closing (see Section 8).


The rear quarter windows may also be operated independently of the convertible top when the convertible top is closed, by means of the ROOF switch on the centre console, as described below.

To lower: Briefly press the rear of the switch. The rear quarter windows will be driven down fully.

To raise: Press the front of the switch. The rear quarter windows will rise for as long as the switch is held.

Notes On Rear Quarter Window Operation:

1. When the convertible top is opened the rear quarter windows are automatically lowered and cannot be operated until the top is closed. When the top is closed the rear quarter windows are automatically raised.
2. The rear quarter windows operate together and cannot be operated individually.
3. Holding the ROOF switch after the warning sounds will cause unwanted convertible top operation.



Exterior Lighting

All the exterior lights, with the exception of the front and rear fog lamps, are controlled by the left-hand column switch.

Note: The button on the end of the column switch, cycles through the message display functions.

Sidelights, Dipped Headlamps (except Scandinavia)

The rotary collar has four positions. These are:

OFF Position (A) – All exterior lights OFF.

Sidelights ON (B) – Switches ON front sidelights, tail, number plate and any other marker lights required by local legislation. In this position the sidelight tell-tale will be lit.

Headlamps ON (C) – Switches ON headlamps (with ignition in position 'II') in addition to the lights switched on in position (B).

Auto Headlamps ON (D) –


If the ignition is switched to position '0', with the rotary collar in the headlamp ON position, sidelights, tail and number plate lights will stay on but the headlamps will switch OFF. When the ignition is again moved to position 'II' they will come on automatically.

Sidelights, Day Time Running Lights (Scandinavia only)

The rotary collar has three positions. These are:

OFF Position (A) – Dipped headlamps, sidelights, tail, number plate and side marker lights will switch ON automatically when the ignition is turned to position 'II'.

Sidelights ON (B) – All the lights switched on in the OFF position (A) will stay on, except the dipped headlamps which will switch OFF.



Headlamps ON (C) – This position gives the normal headlamp and sidelight function.

3-26 Instruments - Controls

Auto Headlamp (D) (where fitted)

A sensor control mounted on the back of the interior rear view mirror, monitors exterior light levels and automatically switches the sidelights and dipped headlamps ON and OFF.

The ignition switch must be in position 'II' for automatic operation.

To operate: Turn the rotary collar to AUTO.

When light fades to the pre-determined level, the sidelights and headlamps will switch ON after a short delay.


The sidelight tell-tale will light up when the headlamps come on automatically.

As light increases to the pre-determined level, the sidelights and headlamps switch OFF after a short delay.

The sensitivity level can be adjusted by turning the sensor control knob on the back of the interior mirror, anti-clockwise to decrease or clockwise to increase when sitting in the driver's seat.

We recommend that the rotary collar on the column switchgear is left on the AUTO position at all times as a convenience feature.

Do not cover the sensors and keep the windscreen clean. Obstructing the light in this area may lead to unwanted operation of the sidelights and headlamps when the switch is set to AUTO.



Headlamp Main Beam (High Beam)

With the lighting switch in the Headlamps ON position (C), push the column switch away from the steering wheel. The blue warning light on the instrument cluster comes ON.

To flash the main beam headlamps, pull the column switch towards the steering wheel. The headlamps will remain ON for as long as the switch is held.

The main beam can be flashed with the ignition ON or OFF and the lighting switch in any position.

Note: Always switch to dipped headlamps when approaching traffic or when driving in urban areas.

Instruments - Controls 3-27

Direction Indicators

The direction indicators operate when the ignition is in position 'II'. To indicate for a right or left turn, move the column switch UP or DOWN respectively. The switch will latch in position and cancel when the turn is completed.

An audible warning and a flashing green warning light on the main instrument cluster indicate that the direction indicators are on.

Headlamp Levelling (A)

The headlamp levelling rotary switch is on the centre console switchpack and operates when the headlamps are switched ON. Turn the switch to the position appropriate for the vehicle load. (Push and release to extend the switch for ease of operation. After use, push again to retract.)

Position '0': Driver and front passenger without luggage.

Position '1': Driver and front passenger with some luggage.

Position '2': Driver, front passenger and rear passenger(s) or heavy luggage.


Position '3': Vehicle fully laden at the rear.

Fog Lamps (B and C)

The switches are on the centre console switchpack and only work when the ignition switch is in position 'II'.

Front Fog Lamp (B): only works with the 'sidelights' or 'headlamps' switched ON.

Note: Front fog lamps should not be used in conjunction with the headlamp main beam (high beam).



Rear Fog Lamp (C): only works with the headlamps switched ON or the front fog lamps switched ON.

Press to switch the fog lamps ON. Press again to switch OFF. LEDs in the switches indicate when the fog lamps are ON.

When the sidelights are switched OFF, the fog lamps will automatically be cancelled.

If the sidelights switch is left ON when the ignition switch is turned to position '0', the fog lamps will switch OFF until the ignition switch is returned to position 'II'.

3-28 Instruments - Controls

Hazard Warning Switch (D - illustration on page 3-27)

The switch is in the centre console switchpack and operates with the ignition ON or OFF.

Press to switch the lamps on. The direction indicators, repeaters (where fitted), tell-tales and audible warning will operate in unison. The switch will light up. To cancel, press the switch again.

Bulb Failure Monitoring

The tail and brake light bulbs are monitored for failure.

Message: **Bulb Fail Rear** Priority Indicator: **Amber**

Headlamp Convenience

When approaching the vehicle, the sidelights and dipped headlamps can be switched ON by pressing the 'headlamp' button on the key-ring transmitter. The lights will come ON for 25 seconds or until the 'headlamp' button is pressed again.


Interior Lighting

Interior lights are fitted in the roof console (map lights) and the driver and passenger footwells. The rear of the cabin is lit by a single roof mounted light (coupe only).

The interior lights can be switched ON independently by pressing the appropriate switch. If the ignition is in position '0' the light will go out after 15 minutes.

All interior lights fade ON and fade OFF when switched. For driver convenience, the lights operate in the following manner:

The lights come ON when either door is opened and stay ON for 15 seconds after both doors are closed. If a door is left open the lights will go out after 2 minutes.



If the engine is running the lights go out as soon as both doors are closed.

If the lights are OFF when the last door is closed the lights will come ON for 15 seconds.

Locking the vehicle or starting the engine switches the lights OFF immediately.

When the vehicle is unlocked by either key or key-ring transmitter, the lights will come ON at $\frac{3}{4}$ maximum brightness (for a maximum of 2 minutes if the door is not opened) and then switch to maximum brightness when a door is opened.

Note: The luggage compartment, vanity mirror and glove box are illuminated when in use. These lights and the map lights will work for up to 15 minutes after the ignition has been switched to position '0', if no other switch is operated.


Instruments - Controls 3-29

Door Guard Lights

Door guard lights are fitted to each door to illuminate the 'step-out' area at night and to give warning of an open door to overtaking vehicles.

The light comes ON automatically when the door is opened and switches OFF when the door is closed.

If the door is left open the light remains ON for 5 minutes and then switches OFF.



Handbrake

The handbrake lever is mounted on the outboard side of the driver's seat and mechanically operates the rear parking brakes. The parking brakes are independent of the main brake system.


To apply: Lift the lever firmly. The handbrake should be fully ON after three or four clicks. The lever may then be returned to the lower (OFF) position with the brake still engaged. This allows the driver easy access to and from the vehicle. The **Handbrake On** warnings will be activated (see below).

To release: Lift the lever fully, press the locking button at the end of the lever, and lower to the OFF position. If the handbrake lever is not fully OFF, the **Handbrake On** warnings will stay on (see below).


Handbrake On Warnings

The handbrake warning/brake fluid low warning light will illuminate and a text message will be displayed.

Message: **Handbrake On** Priority Indicator: **Red**



3-30 Instruments - Controls



Windscreen Wipers and Washers

The windscreen wipers and screen wash functions controlled by the right-hand column switch, only operate with the ignition in position 'II'.

The functions are as follows:

- Position '0' (A): The windscreen wiper blades are OFF and parked.
- First position (B): Intermittent wipe.
- Second position (C): Normal wiper operation.
- Third position (D): High speed wiper operation.

Intermittent Wipe

When intermittent wipe is selected, first position (B), the rotary collar can be adjusted to vary the delay between wipes. Six collar positions (five with rain sensitive wipers fitted) vary the delay from 2 seconds to 20 seconds. Turn the collar anti-clockwise to increase the delay time.

If flick wipe or wash/wipe is selected between intermittent wipes, the intermittent mode will be interrupted temporarily.

Rain Sensitive Wiper Operation (when fitted)

When AUTO, turn the rotary collar to AUTO, and intermittent wipe, position (B), is selected, the wipers will automatically operate to clear the windscreen when rain falls on to the windscreen, or when moisture is present.

Note: When starting a journey with a wet windscreen, the rain sensing wipers will not operate immediately the ignition is switched on, therefore, a flick wipe should be used to clear the screen of any moisture.

Caution: Ensure that AUTO is not selected when entering a car wash or damage to the wiper blades/arms can occur.

Instruments - Controls 3-31

Flick Wipe

Pull the column switch towards the steering wheel for a single slow speed wipe. Holding the column switch in this position will operate the wiper continually at slow speed until released.

Programmed Wash/Wipe

Push the button on the end of the column switch to obtain the wash/wipe programme. A short press will operate the washers briefly and the wipers will complete three wipes. If the button is held, the washers and wipers will operate continuously for up to 20 seconds. When released, the wipers will complete three wipes after the washers have stopped. The drip wipe function will perform a single wipe 4 seconds after the wash/wipe sequence has finished.

When the washer fluid is low, a message is displayed, and the programmed wash/wipe function is disabled. Manual operation is still available.

Message: **Washer Fluid Low** Priority Indicator: **Amber**

Headlamp Powerwash (where fitted)


Note: The telescopic headlamp powerwash units are contained within the headlamp cluster. When operated, the units extend under water pressure, spray the headlamps and then retract automatically into the headlamp.

The headlamp powerwash feature will operate if the ignition is in position 'II' and the lighting switch is in the dipped or main beam position (C). It will not operate if the washer fluid level is low (indicated by the message centre).

When the wash/wipe button is pressed, the headlamp powerwash directs two short bursts, approximately 6 seconds apart, at the headlamp cluster. If the wash/wipe button is held, the powerwash cycle will continue for up to 20 seconds.

The headlamp powerwash will operate the first time the wash/wipe button is pressed and thereafter every sixth succeeding wash/wipe operation. If the sidelights or ignition are switched OFF and ON again, headlamp powerwash will operate on the next press of the wash/wipe button.

3-32 Instruments - Controls



Horns

Twin warning horns are operated by pressing the centre pad on the steering wheel.

The horns will not operate when the ignition switch is in position '0' and the driver's door is open.

Instruments - Controls 3-33

Audible Warnings.

Hazard or Condition	Audible Warning	Remedy
Direction indicators ON.	Ticking. (This will sound at twice normal rate if a bulb fails).	Move left-hand column switch to the centre position when the manoeuvre is complete.
Hazard warning indicators ON.	Ticking. (This will sound at twice normal rate if a bulb fails).	Press hazard warning switch again.
Driver's door opened when the sidelights or headlamps are ON (with the key removed from the ignition switch).	Intermittent slow, high-pitched chime for 10 seconds.	Switch the lights OFF or close the driver's door.
Park not selected with the ignition OFF.	Rapid interrupted low-pitched tone for 10 seconds.	Move the gear selector to 'P' Park.
Driver's seat belt unfastened with the ignition switch in position 'II' (Taiwan and Middle East markets only).	Continuous 6 second tone.	Fasten driver's seat belt or switch ignition to position '0'.
Convertible top starting to close or open.	High-pitched single chime.	
Luggage compartment release switch pressed when in valet mode or valet switch pressed when the luggage compartment is closed.	Low-pitched 1 second tone.	
Seat memory set or recall completed.	Single chime.	
Entry delay warning (European markets only).	Intermittent slow, low-pitched chime.	Disarm vehicle.
Handbrake ON warning.	A single high-pitched tone will sound when the vehicle reaches approximately 3 mph (5 km/h)	Release handbrake.
Airbag system failure. (The audible warning only sounds in the event of airbag warning light failure.)	Five groups of high-pitched tones every 30 minutes	Report the fault as soon as possible to a Jaguar dealer.

3-34 Instruments - Controls

Seats – Adjustments and Driving Position Memory

Front Seats – Electrical Adjustment



WARNING:

1. Do not make adjustments when the vehicle is moving.
2. Front passengers must not ride with the seat reclined.
3. Before making rearward, height or reclining seat adjustments, check that the rear passenger has adequate leg-room.

The front seats can be adjusted electrically by three switches on the side of the seat cushion. Conditions for adjustment are:

- The associated door open or within 30 seconds of closing.
- Key in ignition switch and gear selector in Park or Neutral.

Switch **A** controls the seat cushion position as follows:

Forward or Rearward – Move the switch forwards or rearwards.


Raise/lower cushion – Move the switch up or down (passenger's seat, where fitted).

Switch **B** controls the seat back angle as follows:

Move the switch rearwards to recline or forwards to raise.

Switch **C** controls the lumbar support as follows:

With the ignition switch in position 'I' or 'II', press the **front** of the switch to increase support or the **rear** of the switch to reduce support.



Notes on electrical adjustment of seats:

1. Driving position adjustments must not be made whilst in entry/exit mode.
2. When the gear selector is not in Park or Neutral, seat movement is limited to a maximum of 2 seconds to allow only minor adjustments.
3. With the associated door open the switches are operable. This is to allow adjustment before entering the vehicle, if required.

4-2 Pre-driving

Front Seat Heaters (where fitted)

Each front seat back and cushion has a heater controlled by a switch on the centre console. This function only operates when the engine is running.


To operate: Press the switch.

The heater will only operate if the temperature of the seat is below the pre-set temperature of the thermostat.

To cancel: Press the switch again.

The heater will also switch OFF if the ignition is switched to position '0'.


Note: Storage of the vehicle in a heated garage, body heat or warm ambient temperatures may prevent operation of the seat heater.



Seat Back Tilt

The front seats tilt forward to allow access to the rear seat.

To tilt the seat forward: Lift the knob and push the seat forwards. The seat will latch when returned to the normal position.



Driving Position Memory System (where fitted)

Setting a Driving Position (Memory Set)

The position of the driver's seat, steering column and exterior rear view mirrors can be memorised and recalled. Two different driving position profiles can be entered in the memory.

Storing a driving position profile in the memory can only be achieved with the ignition switch in position 'I'.


1. Adjust the seat, steering column and exterior rear view mirrors to the desired position.
2. Push the memory (M) button. The LED in the switchpack next to the button will come on for a 4 second period, during which time the driving position profile must be entered.
3. Push the button '1' or '2' to memorise the configuration. The memory button light will go out and a chime will indicate that the setting procedure is complete.

By repeating these three steps and pressing the unused button (1 or 2), a second driving position can be stored in the memory.

To set a new driving position, adjust to the desired position and perform steps 2 and 3. The previous memory will be erased and the new position will be set.

Recalling a Memorised Position

To recall a memorised position: press and hold the appropriate memory button (1 or 2) until all seat, steering column and door rear view mirror movement has stopped. A chime will sound when the memorised position is reached.



Driving Position Memory System Operating Tips

- When making adjustments to a set driving position, reset the new position in the same memory channel.
- A driving position will only be memorised if the ignition switch is in position 'I' and the memory button light is ON (4 second period).
- Previous memory is erased when a new driving position is entered.
- Memorised driving positions cannot be recalled whilst the vehicle is in motion.

4-4 Pre-driving

Steering Column Tilt and Reach Adjustment

Manual Operation (where fitted)



WARNING:

Do not adjust the steering column whilst driving.

To adjust tilt: Hold the steering wheel, pull the release lever (A) towards the wheel and hold. Move the steering wheel up or down as required, then release the lever to lock the column in position.

The tilt adjustment includes a non-latching entry/exit position that allows the column to be tilted upwards above the normal driving range.




WARNING:

The vehicle must not be driven with the column in this position.

To adjust reach: Hold the steering wheel, pull down the release lever (B). Move the steering wheel in or out as required, then raise the lever to lock the column in position.

After adjusting for reach, ensure that the column has locked into position.



Electrical Operation (where fitted)



WARNING:

Do not adjust the steering column whilst driving.

The steering column can be adjusted for tilt and reach by operating the four-way control switch on the steering column.

To adjust the steering column the ignition must be in position 'I' or 'II' and the gear selector in park or neutral. Adjustments can also be made within 30 seconds of closing the driver's door or putting in the ignition key.

Moving the switch forwards and backwards controls steering column reach. Moving the switch up and down controls tilt.

Entry/Exit Mode – Steering Column Tilt Away


Entry/exit mode is selected by setting the steering column adjustment switch to the AUTO position.

When the key is removed from the ignition switch the steering column will move to the tilt away position, which is its uppermost tilt and innermost reach position.

The steering column position before tilt away is memorised.

When the ignition key is next inserted in the ignition, the steering column will move back to its previously programmed position.

If a new driving position memory is selected, by pressing one of the memory buttons whilst the steering column is tilted away, the steering column will tilt back to the new selected driving position when the key is next inserted in the ignition.



Notes on entry/exit mode operation:

1. If the adjustment switch is moved away from AUTO whilst the steering column is tilted away, the steering column will move back to its memorised position when the key is next inserted in the ignition and the feature is then cancelled.
2. If the adjustment switch is moved during entry/exit operation, steering column movement will stop.

4-6 Pre-driving

Rear View Mirrors

The interior rear view mirror is of the electrochromic type, and is operated by the control button at the base of the mirror. Where electrochromic door mirrors are fitted, they are operated in conjunction with the interior mirror by the same control.

The door mirrors have heating elements which work when the rear screen heaters are switched ON. The mirror heater will clear all ice from the mirror surface.

Caution: Do not use a scraper as this will damage the surface of the mirror.


Door Mirror Dipping – Reversing (Vehicles with memory function) (where fitted)

To give the driver a clear view of the kerb when reversing, the passenger's door mirror can be dipped without erasing the memorised mirror position.

To operate: With the selector switch (B) in either the left or right position and reverse selected, move the toggle switch (A) rearwards and release (one-touch operation).

The mirror will dip by 7°. Further rearward movements of the toggle switch will dip the mirror in 7° increments. The mirror will return to its memorised position when reverse gear is deselected, or the ignition is switched to position '0'.

Operating the toggle switch rearward and forward with reverse gear selected will dip and return the mirror as required.



Door Mirror Adjustment

Adjustments can be made only if the ignition switch is in position 'I' or 'II', or the driver's door is open.

Both door mirrors are adjusted from the driver's door switchpack. The four-way toggle switch (A) moves the selected mirror to the required position. The selector switch (B) selects the mirror to be moved:

Far left position for the left-hand mirror.

Far right position for the right-hand mirror.

When the selector switch is in the centre position, adjustment to either mirror is inhibited.

Door Mirror – Power Fold-Back

To assist parking, the door mirrors can be folded rearwards by operating the toggle switch.

For power fold-back to function, the mirror selector switch must be in the centre position, and the vehicle speed below 19 km/h (12 mph).


To fold mirrors back: Briefly move the toggle switch (A) rearward and release.

Note: 6 seconds must elapse before folded back mirror can be repositioned.

To reposition mirrors: Briefly move the toggle switch rearward again.

Note:

1. Do not attempt to reposition power fold-back mirrors manually. Always use the toggle switch.
2. After a power supply interruption (battery disconnection) with the mirrors in the normal position, power fold-back will operate on the second press of the toggle switch. Thereafter the switch will operate as normal.
3. Should either mirror be knocked out of position and repositioned manually, the mirror head will be loose. To re-engage the mechanism, power the mirror to the foldback position, then back out to the drive position.



Interior Rear View Mirror

Note: Should the mirror assembly become detached from the windscreen, it must be refitted by a Jaguar Dealer.

The interior rear view mirror is of the electrochromic type, and is operated by the control button at the base of the mirror.

When switched on, the mirror darkens automatically to prevent glare from a following vehicle's headlamps, and clears when light levels return to normal or when reverse gear is selected.

Where electrochromic door mirrors are fitted, they are operated in conjunction with the interior mirror by the same control, and function in the same manner.

To operate: To switch ON, press the control button. An LED lights up to indicate that automatic operation is selected. Press again to switch OFF.

4-8 Pre-driving

Inertia Switch

In the event of an accident, an inertia switch will trip, isolating ignition controlled circuits, including fuel pump operation. Simultaneously, the doors will automatically unlock. Once the switch has tripped it must be reset before attempting to restart the engine.

Note: The doors will not unlock if the inertia switch is tripped when the ignition switch is in position '0'.

The inertia switch is located in the left-hand fascia fusebox, behind a pull-out panel. To remove the panel, first open the left-hand door. A button on the top of the switch, under a flexible cover, is raised when the switch has been tripped.

Resetting the switch




WARNING:

To avoid the possibility of fire or personal injury, do not reset the inertia switch if you see or smell fuel.

If no fuel leak is apparent, reset the inertia switch as follows:

1. Turn the ignition switch to position '0'.
2. Press down the flexible cover on the top of the inertia switch.
3. Turn the ignition switch to position 'II', pause for a few seconds, then return the key to position '0'.
4. Make a further check for fuel leaks.




Ignition/Starter Switch and Steering Lock

This switch is on the right-hand side of the steering column. It is operated through four positions by the ignition key.

Note: Should any warning lights or warning messages stay on after starting the engine, the cause must be investigated before driving off.

- 0. The only position in which the key can be inserted or removed. When the key is out, the steering lock is engaged.
- I. **Auxiliary position:** Certain circuits, i.e. radio, windows, can be operated without switching on the ignition.
- II. **Ignition position:** All circuits except the starter motor are actuated. The key remains in this position when driving.
- III. **Start position:** The starter motor is operated for as long as the key is held in this position, against spring pressure. If the engine fails to start, the key must be returned to position 'I' before another start is attempted.



4-10 Pre-driving

To Disengage Steering Lock and Start Engine

Insert the key and turn clockwise. If resistance is felt, turn the steering wheel slightly to release the steering lock.

Turn the key to position 'II' to switch on the ignition.



WARNING:

Before starting the engine, check the handbrake is ON and the gear selector lever is in position 'P' or 'N'.

To start the engine, turn the key to position 'III'. When the engine starts, release the key which will return to position 'II'.

Note: Do not depress the accelerator pedal whilst operating the starter motor.

Do not use the starter continuously for longer than 6 seconds. Wait until the engine stops before re-using the starter.

If the engine persistently fails to start it is possible that the engine is flooded with fuel. Turn the ignition off, then on and wait until the bulb check is completed. Slowly depress the accelerator pedal fully, hold it in this position and start the engine. Release the pedal when the engine starts.

If the engine still fails to start, switch the ignition OFF and contact a Jaguar Dealer. Continued use of the starter will discharge the battery and may also damage the starter mechanism.

If the ignition circuits are isolated, the fuel system inertia switch may have tripped, and will require resetting (See page 4-8).



WARNING:

Never switch OFF the (ignition) engine whilst the vehicle is in motion as the steering lock may operate.

Due to the installed starter non-repeat feature, the key must be turned to position 'I' before attempting to start the engine again.

When the engine starts, check the oil pressure gauge, if fitted. Do not increase engine speed before pressure registers on the gauge. If the gauge is not fitted, do not increase the engine speed until the oil pressure warning light goes out.

The red ignition warning light should go out when the engine is running.

To Stop Engine and Lock Steering

Turn the key from position 'II' to the 'lock' position '0'. This stops the engine.

The ignition key cannot be removed from the ignition switch/steering lock unless the gear selector lever is in position 'P'.

Once the ignition key has been removed the gear selector lever will be locked in position 'P'.

A manual release mechanism will allow the gear selector lever to be unlocked from the 'P' position in the event of electrical failure or when moving the vehicle without power (i.e. towing). Removal of the ignition key actuates the steering lock. Slight movement of the steering wheel may be needed to engage the lock fully. Always remove the keys when leaving the vehicle. Leaving the key in position 'I' will discharge the battery.

Fuel Filler Flap and Cap



The fuel filler is on the left-hand side of the vehicle.

The filler flap is operated by the release switch on the driver's knee bolster. The switch will not operate with the engine running. The vehicle must be unlocked or the ignition switch in position 'I' or 'II'.

To unlock, press the release switch. The filler flap will open partially. Fully open filler flap.

Turn the filler cap anti-clockwise and remove. Place the cap against the magnetic plate on the inside edge of the filler flap.

After refuelling, refit the filler cap and close the flap firmly to lock.



Fuel Filler Flap Emergency Release

In the event of a power failure the flap can be released as follows:

1. Remove the luggage compartment lining at the rear on the left-hand side below the filler.
2. Reach up and locate the fuel filler flap mechanism. The lock plunger has an 'L' shaped bracket at one end. Pull back the plunger to release the filler lock

After refuelling, refit the filler cap and close the flap firmly to lock.

4-12 Pre-driving

Fuel Tank Filling



WARNING:

1. Fuel vapour is highly flammable and in confined spaces is explosive and toxic. In the event of inadvertent spillage, and before refuelling, always switch OFF the engine. Do not use exposed flame or light. Do not smoke. Do not inhale fumes.
2. Do not fill the tank so that fuel is visible in the fuel filler intake tube. This could cause spillage and danger from exposed fuel.

The use of either leaded or unleaded fuel depends on the type of emission control system fitted to the engine and the legislative requirements in the country for which the vehicle is manufactured.

See **Fuel Requirements** in SECTION 6 of the Vehicle Care Handbook for information on recommended types and grades of fuel.

If in doubt your local Jaguar Dealer will advise on which fuel must be used in your vehicle.

Always use a high quality fuel which contains detergent and other additives. These will help to protect the engine components against corrosion and carbon deposit formation, and prevent contamination of the fuel injection system.

The continuous use of high quality fuel makes the need for additional additives unnecessary.

When filling, the dispenser nozzle must be inserted into the filler neck sufficiently to open the trap door for fuel to flow into the fuel tank. Fill the tank until the filler nozzle automatically shuts off. Filling beyond this point could result in fuel spillage.

Unleaded Fuel

Vehicles with engines fitted with catalytic converters must only be filled with 'Unleaded Fuel'.

Use unleaded fuel with an octane rating of at least 95 RON (Research Octane Number).

Note: 'Super Green' Plus 98 RON unleaded fuel (where available) may be used as an alternative to the standard 95 RON unleaded fuel.

The filler neck of the fuel tank is a small diameter to prevent the larger diameter nozzle of a leaded fuel pump entering.

Japan only: Use only unleaded fuel, the filler neck of the fuel tank on these vehicles is of a large diameter.

Leaded Fuel

This fuel must only be used on vehicles which are not fitted with catalytic converters.

Occupant Protection – Seat Belts and Airbags

This vehicle has lap/shoulder inertia reel seat belts and an airbag supplementary restraint system for the driver and front passenger seat. The rear seat has lap/shoulder inertia reel seat belts.

The use of front and rear seat belts is mandatory in most countries.

Using seat belts saves lives. They should be worn by all occupants whenever the vehicle is in use, for maximum protection.

Seat Belts

The inertia operating mechanism of the seat belts allow the wearers to move their upper bodies to reach various controls. The seat belts will lock automatically with accelerated body movement or in the event of emergency braking.

The only adjustment required is for shoulder height (coupe only, see page 4-16). Correct tension is controlled by automatic retraction of the reel.

A warning light on the instrument panel comes on when the driver's seat belt is not fastened. (In some markets a warning signal sounds for 6 seconds).

The use of comfort clips or devices that would create slackness in the seat belt system are not recommended.

The seat belts fitted to the vehicle are also to the specification approved by Australian Design Rules.



WARNING:

1. Seat belts are designed to bear upon the bony structure of the body, and must be worn low across the front of the pelvis, chest and shoulder. Wearing the lap section of the belt across the abdominal area must be avoided.
2. Seat belts should be adjusted as firmly as possible, consistent with comfort, to provide the protection for which they have been designed. A slack belt will greatly reduce the protection afforded to the wearer.
3. Care should be taken to avoid contamination of the webbing with polishes, oils and chemicals, and particularly battery acid. Cleaning may safely be carried out using mild soap and water. The belt should be renewed if webbing becomes frayed, contaminated or damaged.
4. It is essential to renew the entire assembly after it has been worn in a severe impact even if damage to the assembly is not obvious.
5. Belts should not be worn with straps twisted.
6. Each seat belt assembly must only be used by one occupant; it is dangerous to put a seat belt around a child being carried on the occupant's lap.
7. No modifications or additions should be made by the user which will either prevent the seat belt adjusting devices from operating, or prevent the seat belt assembly from being adjusted to remove slack.

4-14 Pre-driving

All passenger's seat belts (not the driver's) also have an automatic locking device for use with child seats. The belt, once fitted to secure a child seat with all the slack removed, will automatically lock in this position and further extraction of the belt is inhibited.

To activate the static reel (child seat) mode, pull the belt to its full extension to engage the ratchet mechanism. With the child seat in the required position insert the belt's tongue into the buckle. Retract the belt back onto the reel; a ratchet operation may be felt as the belt retracts. Continue to pay the belt back onto the reel until it fits snugly around the child seat.

Unclipping the belt buckle and releasing the child seat will allow the belt to resume its normal operation.

To release the seat belt, press the button on the buckle unit and allow the belt to retract into the reel.

Inertia Reel Mechanism Check

To provide the users with maximum freedom during normal driving conditions, the seat belts are inertia reel type. Hard braking, fast cornering or belt movement locks the belts immediately.

Static test: Whilst seated, fasten the seat belt and grip the shoulder belt at approximately shoulder level with the opposite hand. Pull the belt sharply downwards, the belt should lock.

Road test: The following road test must be carried out only under maximum safe road conditions.

With the seat belt fitted to the driver and passenger, as previously described, drive the vehicle at 8 km/h (5 mph) and, ensuring that it is safe to do so, brake sharply.

The seat belt(s) should lock automatically, holding both driver and passenger securely in position.

It is important when braking that the reactions of both driver and passenger are normal, i.e. the body must not be thrown forward in anticipation, thus causing a 'snatching action of the belt which would operate the locking mechanism'.

If the belt fails to lock on either test, consult a Jaguar Dealer.

Note: If the vehicle is parked on unlevel ground, the seat belt mechanism may lock. This is not a fault, ease the belt from its attachment to fit.

Care of Seat Belts


Avoid contaminating the webbing with polishes, oils and chemicals.

The belts must not be allowed to rub against seats or bodywork. Seat belts that have been cut, frayed, damaged or used in vehicles involved in accidents must be renewed.

Cleaning

An occasional wipe with a warm soapy sponge will keep the seat belts clean. Do not use bleach or dye, otherwise the efficiency of the seat belts will be impaired.

Pre-driving 4-15



Front Seat Belt Fitting and Adjustment

Draw the tongue of the seat belt over the shoulder, across the chest and push it into the buckle unit slot. A positive 'click' indicates that it is safely locked.

Always ensure that the webbing is midway between the neck and the edge of the shoulder.

To release the harness, press the button on the buckle unit and allow the belt to retract into the reel.



WARNING:

Should the seat belt not retract and remain at its static length, consult your nearest Jaguar Dealer immediately.

4-16 Pre-driving

Shoulder Height Adjustment (Coupe only)



WARNING:


Do not adjust the seat belt or anchorage point while driving.

An adjustable anchorage point is provided to ensure that the seat belt webbing can be positioned to pass over the shoulder without pulling against the neck.

To operate: Press the locking button and slide the anchorage point to the required position to ensure comfort and safety. Release the button and check that the anchorage point is locked.

Always ensure that the webbing is midway between the neck and the edge of the shoulder.

Always check the anchorage point after the seat has been adjusted to ensure that the belt is correctly positioned.




Rear Seat Belts Fitting

The belts are of the lap/shoulder reel inertia type. Draw the tongue of the seat belt over the shoulder, across the chest and push it into the buckle slot nearest the wearer. A positive 'click' indicates that it is safely locked.

Always ensure that the webbing is midway between the neck and the edge of the shoulder.

To release the harness: press the button on the buckle unit and allow the belt to retract into the reel.



4-18 Pre-driving

Airbags



In order to provide optimum protection this vehicle is equipped with driver and front seat passenger airbags. **They are supplemental to seat belts which should be worn by all occupants whenever the vehicle is in use, for maximum protection.**

The driver airbag is located in the centre of the steering wheel and the front seat passenger airbag is located in the fascia panel immediately in front of the passenger seat.



WARNING:

1. No objects whatsoever should be attached to the centre cover of the steering wheel or the passenger fascia panel.
2. **Child seats and passenger airbag:**
Children of 12 years old and under can be killed or seriously injured by the airbag. The rear seat is the safest place for children.
DO NOT install a rearward-facing child seat in the front passenger seat position. This is emphasised by the label displayed on the end of the fascia on the front passenger side, as shown on the illustration.
If however, you must sit a child in the front passenger seat use only a forward facing child seat with the passenger seat set fully rearward. Always follow the fitting instructions supplied with the appropriate child restraint system.
3. Driver and front seat passenger should always move their seats back as far as practical.



Pre-driving 4-19

The airbags are designed to inflate in severe frontal collisions that occur within the shaded area shown. They will not deploy at very low speeds or in side and rear impacts.

In circumstances where the airbags are not deployed, protection is provided by the seat belts. The severity of the collision is a function of the relative speed and weights of the vehicle or objects colliding.


The airbags are electrically activated and self contained within the steering wheel hub and the fascia panel. The whole sequence of events from sensing the impact to full inflation of the bag takes place in a fraction of a second. As the occupant restrained by the seat belt moves forward, the head and chest come into contact with the inflated bag which then deflates in a controlled manner, via vent holes to absorb the remaining energy of the impact.

The noise and gas associated with the deployment of the airbags is not injurious to health.

All work on the airbag system, including renewal after deployment and renewal at the end of its service life, must be carried out by an authorised Jaguar Dealer.

In the event of the vehicle being dismantled, airbag module disposal instructions can be obtained from an authorised Jaguar Dealer. Instructions are also reproduced in the Service Manual.

Airbag warning information (see illustration) is printed on the driver's and passenger's sunvisor.



4-20 Pre-driving

Child Safety



WARNING:

Child seats and passenger airbag:
Children of 12 years old and under can be killed or seriously injured by the airbag. The rear seat is the safest place for children.

DO NOT install a rearward-facing child seat in the front passenger seat position. This is emphasised by the label displayed on the end of the fascia on the front passenger side, as shown on the illustration.


If however, you must sit a child in the front passenger seat use only a forward facing child seat with the passenger seat set fully rearward. Always follow the fitting instructions supplied with the appropriate child restraint system.

In many countries legislation governs how and where children should be carried when travelling in a vehicle. It is the responsibility of the driver to comply with all regulations in force in the country where the vehicle is being used.

Holding a baby or child in a person's arms is not a substitute for a child restraint system.

In an accident a baby or child held in a person's arms can be crushed between the vehicle's interior and a restrained person. The child can also be injured by hitting the interior or by being thrown from the vehicle during a sudden manoeuvre or impact.

Injury can also be caused if the baby or child is allowed to ride on the seat unrestrained. Other occupants should also be properly restrained to help reduce the chance of injuring the child.



Do not allow children to stand in the space between the front seats or on the rear seats.

Children must be restrained by the use of a child safety restraint applicable to their weight and size and used in conjunction with one of the rear outboard inertia reel seat belts.

A range of safety restraint devices are available as Jaguar Accessories; consult your Jaguar Dealer for details.

Fitting and instructions for use are included in each kit and must be followed explicitly to ensure proper use.

Wearing of Child Restraints

Ensure that there is no slack in the webbing and that the restraint fits the child snugly across the rib cage and hips. These are the parts of the body most able to take the force of impact.

The lap strap should pass across the top of the child's thighs, bearing on the pelvis, not the abdominal area.



WARNING:

1. Do not try to put an adult seat belt around two children.
2. Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts, harnesses or for attaching other items or equipment to the vehicle.
3. Choose a child seat that sits securely on the seat and against the seat back.

Infants

Babies and small children who cannot sit up by themselves should be carried in an approved baby seat.

Child Restraint Tether Anchorages (Australia only)

Australian Design Rule 34/01 requires that a child restraint anchorage be fitted for each rear seating position.


The coupe and convertible are supplied with child restraint tether brackets already fitted.

Look for the following when selecting a child restraint system:

- It should have a label certifying that it meets the applicable Australian Motor Vehicle Safety Standards.
- Carefully read the instructions supplied with the restraint. Be sure you understand them and can install and use the device properly and safely in the vehicle.
- Ensure that the child restraint system is appropriate for the child's weight and development. The label required by the standard or regulations, or instructions for infant restraints, usually provides this information.


Note: Always ensure that child restraint assemblies are fitted in strict accordance with the child restraint manufacturer's instructions.

4-22 Pre-driving



Child Restraint Tether Brackets – Coupe (Australia only)

The coupe tether brackets are positioned on the rear parcel shelf at the centre-line of each rear seating position. The child restraint can be fitted to the bracket, after sliding off the cover.



Child Restraint Tether Brackets – Convertible

(Australia only)

The convertible tether brackets can be located by reaching down behind the rear seat along the centre line of the seat. The child restraint can be fitted directly to the bracket.


Footrest Adjustment

Footrest and Height Extension

The footrest provided for the driver's left foot is attached to the floor by two bolts. The upper part is a height extension, which if not required can be removed, after first releasing the front clip. When the extension is detached the two bolt hole plugs may remain on the extension. These plugs must be removed and refitted into the bolt holes.

Low-Level Footrest

A low-level, one-piece footrest is available which replaces the standard two-piece fitment. The low-level footrest is available from your Jaguar Dealer.



4-24 Pre-driving

Luggage Retaining Net (where fitted)

The luggage net is used to prevent small items of luggage, bags or parcels from sliding around the luggage compartment floor.


Open the luggage compartment lid and locate the mounting hooks on the underside of the parcel shelf.

Ensure the strap, at the centre of the net is positioned facing rearwards.

Fasten each of the two velcro strips to a convenient floor, side or rear panel carpet.

Fasten a loop at each top corner of the net over the luggage hooks.

Using the strap, pull the net open and place the small items in the pocket formed between the two net layers.



General Driving Information

Before Starting

Before starting the engine, new owners/drivers should familiarize themselves with the layout and operation of the controls and instruments described on preceding pages.



WARNING:

Ensure the handbrake is on and the gear selector is in position 'P' or 'N' before attempting to start the engine.

Attention should also be given to the items in **Regular Checks**, SECTION 3 of the Vehicle Care Handbook.

Disengage the steering lock and start the engine.

Before driving off, check the instruments, warning lights and message centre. Take special note of any warning light that is on.

Seat belts are provided for your safety. It is unwise, and in certain countries illegal, to commence any journey, however short, without wearing them.

Warming Up

Do not operate the engine at high rev/min when first started but allow time for the engine to warm up and the oil to circulate. In very cold weather it is advisable to run the engine at 1500 rev/min with the vehicle stationary (in the open air) until a rise in temperature is indicated on the gauge.

Use of Headlamps in Daylight (Except Scandinavia)

When visibility is poor, the headlamps on dipped beam setting must be switched on so that the vehicle may be seen more easily by other road users.

In conditions of poor daytime visibility, switching the headlamps on manually may be preferable to the use of the Auto headlamp feature.

The instrument illumination control adjusts the brightness of the panel lighting.

Climate Control Solar Sensor

A solar sensor unit is located on top of the fascia on the driver's side below the windscreen. This sensor should not be covered as it is required for climate control sensing.

Emission Control

The emission control systems control the emission of hydrocarbons, carbon monoxide, oxides of nitrogen and fuel by evaporation.

It is essential that routine maintenance operations are carried out by a Jaguar Dealer at the specified intervals.

5-2 Driving

Engine Oil Consumption

A certain amount of oil consumption is normal. The rate of consumption will depend on the following:

- The quality and viscosity of the oil.
- The amount of oxidation and dilution of the oil.
- Climatic conditions.
- The speed at which the engine is being operated.
- Road conditions.

Drivers should expect above normal consumption when the engine is new, and after running-in if high speeds are sustained.

Winter Driving

Freeing a Frozen Door Lock

Caution: Do not apply a proprietary Lock De-icer through the keyhole.

Should the lock become frozen, heat the end of the key before use.

Windscreen Wiper Blades

Before driving away, clear any ice from the windscreen and check that the wiper blades are free.

Frost Precautions

The correct concentration of coolant must be maintained at all times when 'topping up' or 'refilling' the cooling system. See **Checking and Replenishment** in SECTION 3 of the Vehicle Care Handbook.

Winter (Snow) Tyres

The use of winter tyres will considerably improve the vehicle's handling in adverse winter conditions.

Winter tyres must be used in a complete vehicle set. See **Wheel/Tyre Data** in SECTION 6 of the Vehicle Care Handbook for recommended tyres and tyre pressures.

Snow Chains and Spikes Spiders

Snow chains or spike spiders, of the recommended type, may only be fitted to the rear wheels. See SECTION 5 of the Vehicle Care Handbook.

Switch off traction control when using snow chains or spikes spiders.

The maximum speed when using snow chains or spiders is 48 km/h (30 mph).

Remove the snow chains or spikes spiders as soon as the roads are clear of snow.

Running-in

Apart from a few precautionary recommendations, there are no strict 'running-in' procedures for this vehicle.

By observing the following advisory notes you will ensure maximum engine, transmission and brake life for your vehicle.

1. Allow the engine to warm up thoroughly before operating at engine speeds over 3500 rev/min.
2. Vary the speed frequently.
3. From 1500 kilometres (1000 miles) onwards, gradually increase performance of the vehicle up to the permitted maximum speed.

Brakes

The front and rear disc brakes are on separate brake circuits. Should one of the brake circuits fail, the other circuit will still operate. If one circuit fails, brake pedal travel and effort will increase, however, if it is the front circuit which fails, considerably greater travel and effort will be required to stop the vehicle. In any event consult a Jaguar Dealer immediately.

Running-in for Brakes

To ensure that the brake pads can 'bed-in' evenly and reach their optimum wear and performance condition, the following points are recommended.

1. Where possible, avoid heavy braking or rough usage of the brakes as this can result in damage being caused to the brake pads and discs.
2. Avoid prolonged use of the brakes, for example, when descending severe gradients.
3. Frequent light application of the brakes is desirable. This helps to fully 'bed-in' the brake pads before the normal running-in period is completed and the vehicle is operated at high speeds, when maximum brake efficiency will be required.

The above equally applies when new discs or pads have been fitted.

Anti-lock Braking System (ABS *plus*)

This system helps to prevent the road wheels from locking and skidding during emergency braking, assisting the driver to maintain full steering and directional stability. The factor controlling ultimate stopping distance and cornering ability is tyre/road adhesion.

ABS *plus* optimises tyre/road adhesion under maximum braking conditions though it cannot provide increased cornering ability. There is no need for special braking techniques, such as 'pumping' the brakes, to achieve optimum braking distances and control on poor or slippery road surfaces. Tyres must be in good condition to achieve maximum adhesion.

During normal braking the ABS will not be activated. However, if the braking force applied begins to exceed tyre/road adhesion the ABS will automatically activate, preventing the road wheels from locking. In these circumstances a pulsating effect will be felt from the brake pedal indicating that the system is functioning. The pulsating effect is due to small fluctuations in pressure supplied to the brakes by the system to maintain full tyre/road adhesion.

ABS *plus* recognises differences in speed between the four road wheels caused by slip angle and changes in load whether a vehicle is getting into a critical driving situation on bends, on a surface with varying grip or with abrupt steering movements which confront the driver with understeer or oversteer tendencies. ABS *plus* improves dynamic stability by reducing or increasing brake pressure to individual wheels resulting in better directional stabilisation.

Under severe braking on some road surfaces tyre noise may be apparent even though the wheels will at no time become locked.

5-4 Driving



WARNING:

1. It remains the driver's responsibility to drive safely according to prevailing conditions.
2. The fact that a vehicle is fitted with ABS must never allow the driver to be tempted into taking risks which could affect his/her safety or that of other road users.
3. The addition of ABS cannot overcome the consequences of trying to stop in too short a distance, cornering at too high a speed, or the risk of aquaplaning.
4. The driver should always take road conditions into account. A slippery road surface always requires more braking distance for a given speed, even with ABS. A possible increase in stopping distance compared to locked wheels may occur during ABS operation on slushy snow, gravel, sand or some heavily corrugated or ridged warning sections of road surfaces.

ABS Monitoring

The ABS control module monitors the ABS electrical system from ignition switch ON to ignition switch OFF. Any malfunction will be indicated by the anti-lock warning light coming on.

Should a fault develop in the ABS system, the brake system will still operate conventionally and with the same standard of performance as vehicles not equipped with ABS.

Caution: Should the warning light come on while driving, a system failure is indicated, consult a Jaguar Dealer immediately.

Advice On ABS Braking Techniques

For optimum ABS performance the instructions on braking techniques during ABS operation should be followed:

1. Do not release brake pressure when the pulsating effect is felt. Maintain a constant pressure until the manoeuvre is completed.
2. To familiarise yourself with the feel of the brake pedal during ABS braking, practice an emergency stop procedure, always making sure it is safe to do so. With the seat belts fitted to all occupants, drive the vehicle at 32 km/h (20 mph) and brake sharply.
3. ABS enables the driver to steer around obstacles during emergency braking. However, the consequences of turning sharply at high speed cannot be overcome by the ABS. Read the warnings on this page.
4. Do not attempt to 'pump' the brakes to avoid skidding as this can interfere with the ABS operation. The ABS will not allow the wheels to skid under normal road conditions.
5. The ABS will tend to keep the vehicle straight during braking. Because braking distances may increase under certain road conditions, it is necessary to plan and make turning manoeuvres as early as possible.

Touring

Foreign Travel

Before planning foreign travel, check with a motoring organisation to ensure that your vehicle will comply with legal requirements of the countries you intend to visit.

It is advisable to carry vital spare parts to ensure against a breakdown in a remote area.

Touring kits (available in United Kingdom) containing a selection of basic items is available from the Jaguar accessory range.

International motoring organisations are helpful for all aspects of long distance touring advice.

In some countries it is a requirement to carry spare vehicle bulbs.

First Aid Kit

A first aid kit is compulsory equipment in certain countries. Your Jaguar Dealer can supply a first aid kit.

Fire Extinguishers

Many countries make it compulsory to carry a fire extinguisher. Your Jaguar dealer can supply and fit one.

Petroleum Spirit in Containers

Some countries forbid the carrying of petrol in containers, as do most ferry and hovercraft operators.

Cellular Radio Telephones in Tourist's Vehicles Abroad

Ask your motoring organisation about the use of cellular radio telephones before travelling abroad, as some countries exercise controls on the importation and use of such equipment.

Jaguar Warning Triangle

A warning triangle to give following traffic advanced notice of a disabled vehicle is compulsory in many countries. A triangle, designed to international standards, is standard equipment in certain markets.

Hazard warning lights must be used with the warning triangle.

The warning triangle is folded flat and mounted on the inside of the luggage compartment lid.

In an emergency, remove and unfold into a triangle. Place the triangle in the road in accordance with local traffic regulations to give oncoming traffic warning of an immobilised vehicle.

5-6 Driving

Climate Control 6-1

Climate Control System

The climate control system fitted to this vehicle offers automatic control of temperature, fan speed and air distribution to maintain optimum comfort under most driving conditions.

Manual controls are provided to allow the driver to override the automatic operation.

Control Panel

1. a) Push to switch ON or OFF.
b) Rotate for manual fan speed selection.
2. Manual recirculation/outside air.
3. Centigrade/Fahrenheit selection buttons.
4. Display panel.
5. External temperature.
6. Air conditioning.
7. Automatic operation.
8. Manual distribution (from left to right):
 - Face only.
 - Bi-level (Face and feet).
 - Feet only.
 - Demist (Screen and feet).
9. Temperature selection:
Blue – Decrease.
Red – Increase.
10. Heated rear screen.
11. Heated front screen (where fitted).
12. Defrost.

General Information


Ensure that the air inlet grille at the base of the front windscreen is clear of leaves, snow or other obstructions.

A solar sensor unit is mounted on the top of the fascia, this should not be covered when driving.

The intake grille of the in-car temperature sensor is located on the lower fascia, driver's side. To ensure optimum temperature control this grille should not be obstructed.

Condensate which forms at the evaporator in the air conditioning unit is discharged onto the road underneath the vehicle. After stopping, puddles of water will form underneath the vehicle.

The refrigeration system (A/C button) should be run briefly at least once a week to lubricate the compressor seal and prevent refrigerant leakage.



6-2 Climate Control

System Operation and Button Functions

Switching the System On

The system can be switched on by pressing one of the following:

1. 'AUTO' button – Switches the system on in automatic mode.
2. 'DEF' button – Switches the system on in defrost mode.
3. 'A/C' button – Switches the system on in the last setting and with the refrigeration system working.
4. 'Push Off' knob – Switches the system on in the last setting.

Automatic Operation



Note: The fans will not operate until the engine is warm (except in defrost).

Press 'AUTO' for optimum automatic control under most operating conditions. The word 'AUTO' will appear in the display panel and the temperature, fan speed and distribution will be controlled automatically.



Air Conditioning



Press to switch off the refrigeration system. Press again to switch on. The refrigeration system is automatically engaged when 'AUTO' is selected.

All the year use of air conditioning is recommended for optimum comfort and to reduce interior misting.

Temperature Selection



The selected interior temperature is shown in the display panel. Press the 'red' button to increase the temperature. Press the 'blue' button to decrease the temperature.

Automatic temperature control operates between 17° C and 31° C (61° F and 90° F). In addition, 'HI' and 'LO' settings provide maximum heating or cooling at maximum fan speed. Fan speed can be manually reduced as required.

Defrost



Press 'DEF' to direct air to the front and side screens at maximum fan speed. This also switches on the heated front screen (if fitted). Fan speed can be manually reduced as required. Press 'DEF' again to return to the last setting or 'AUTO' for automatic control.



WARNING:

Directing cold air onto the screen in warm humid conditions can produce external condensation.

Climate Control 6-3

Manual Air Recirculation



Closes the outside air intakes and recirculates air within the vehicle. Prevents unpleasant odours being drawn into the vehicle.

Two options of control are available:

1. Press the button to provide recirculation of interior air for a period of approximately five minutes.
2. Press and hold the button until two 'beeps' are heard to provide continuous recirculation of interior air. Press the button again to switch off.



WARNING:

Avoid using Manual Air Recirculation for prolonged periods in cold weather as this may result in interior misting of screens.

Heated Front Screen (where fitted)




With the engine running, press to switch on the heated front screen for rapid defrost/demist. It is automatically engaged when 'DEF' is selected but can be independently switched on or off at any time. Automatically switches off after approximately six minutes.

Heated Rear Screen



With the engine running, press to switch on the heated rear screen and heated door mirrors for rapid defrost/demist. It can be independently switched on or off at any time. Automatically switches off after approximately 20 minutes.


Manual Fan Speed




Note: In 'AUTO' the fans will not operate until the engine is warm.

Turn the rotary knob clockwise to increase or anti-clockwise to decrease air flow. Fan speed is displayed as a series of bars, and the word 'AUTO' will disappear.

Press 'AUTO' to resume automatic control.



Celsius/Fahrenheit Selection



Press 'F' to display temperature in Fahrenheit.

Press 'C' to display in Celsius.

6-4 Climate Control

Manual Air Distribution

The following options are available:



Face only



Bi-level (face and feet)



Feet only



Demist screen and feet




WARNING:

Directing cold air onto the screen in warm humid conditions can produce external condensation.

Press the required button (the word 'AUTO' will disappear from the display panel). Press the button again or press 'AUTO' to resume automatic control.

External Temperature



Two options are available for displaying the external temperature:

1. Press the button to provide a display for approximately 4 seconds.
2. Press and hold the button until two 'beeps' are heard to provide a continuous display of external temperature. Press the button again to switch off.

Switching Off/Ventilation Airflow



Press the 'Off' knob to switch off the climate control system and prevent outside air from entering the vehicle.

If ventilation is required with the system off, press the desired manual air distribution button. This will provide unconditioned air only when the vehicle is moving.

Note: Heated screen and external temperature display functions can be selected when the system is off.

Operating Tips

If the vehicle has been parked in the sun the interior will cool faster if you follow these guidelines:

- Before sitting in the vehicle, leave door(s) open for a short time to allow the hot air to escape.
- Drive for a short time with the windows open to force the hot air out of the vehicle.

All the year use of air conditioning is recommended for optimum comfort and to reduce interior misting.



WARNING:

To prevent humidity build up inside the vehicle and possible screen misting, avoid driving with the system off or in manual air recirculation for prolonged periods.

Convertible Vehicles

When driving with the convertible top down it is recommended that manual overrides are selected.

Air Distribution

The illustration on the next page shows the location of the air vents within the vehicle.

Air distribution is automatically controlled when 'AUTO' is selected. Manual control can be achieved using the air distribution buttons.

Airflow from the fascia vents can be regulated or switched off using the thumbwheel controls on those vents. The airflow through these vents may be directed by adjusting the vanes.

Item (A) shows the solar sensor.


System Fault Display

The climate control system is equipped with self diagnostics.

If a fault is detected, the symbol 'Er' will appear in the display accompanied by a series of beeps for 5 seconds. In this unlikely event the vehicle should be returned to the Jaguar Dealer at the earliest convenience.

'Er' will be displayed on each subsequent vehicle start until the fault is rectified.

6-6 Climate Control



Interior Features 7-1



Sun Visors and Vanity Mirrors

Adjustable sun visors can be swung downwards or unclipped and swung sideways to eliminate sun glare.


The rear of each sun visor is fitted with an illuminated vanity mirror, behind a hinged flap. The light comes ON when the flap is lifted.

Note: Vanity mirror illumination will only work when the sun visors are held in place by the stowage clips.

When positioned to the side, the sun visors can be moved forwards or rearwards on a telescopic arm, if required.



7-2 Interior Features



Interior Features 7-3

Sunglasses Stowage Compartment

Stowage for the driver's sunglasses is provided in the driver's knee bolster (A).

To open: Pull down using the finger recess.

Glove Compartment

A glove compartment (B) is situated below the passenger's airbag. This compartment may be locked using the black-headed key only.

To open: Lift the handle and allow the lid to drop down. The compartment will be illuminated when open.

Note: The compartment will be illuminated for up to 15 minutes after the ignition has been switched to position '0'.

Stowage is provided for: the Driver's Handbook Literature Pack, pen holder and a rechargeable torch (available as an accessory).

Centre Console Armrest

The armrest (C) is hinged at the rear to provide access to a storage compartment, and incorporates a cupholder (where fitted) which is described below.

On vehicles fitted with the optional GSM telephone, the storage compartment is fully occupied by the handset and vehicle interface.

Cupholder (where fitted)

A cupholder (D) for two cups is provided in the centre console armrest.

To operate: Push the button on the armrest rearwards. After use, lower the cupholder flap and press down to engage the latch.

Do not use the cupholder while the vehicle is moving. Do not open the storage compartment while the cupholder is being used.

Ashtray and Cigar Lighter

The ashtray and cigar lighter (E) is situated in front of the cupholder.

To open: Press the front edge of the lid which will open to reveal the cigar lighter and removable tray.

To operate the cigar lighter: With the ignition in position 'I' press down and wait until the element has heated, it will then 'pop-up'.

Note: Never hold the lighter knob down. Do not attempt to remove particles from the element, as it is self cleaning.

To empty the tray: Lift out vertically and remove.

7-4 Interior Features

Exterior Features 8-1

Power-Operated Convertible Top

The power-operated convertible top and rear quarter windows are controlled by the switch marked 'ROOF' which is located just above the gear selector 'J' gate. The top latches and unlatches automatically. It should not be opened or closed when the vehicle is being driven, however, for convenience it may be operated at low speeds below 16 km/h (10 mph).

For the operating mechanism to function the ignition key must be in position 'I' or 'II'.



WARNING:

Before opening or closing the convertible top ensure that all occupants have moved their hands, fingers, hair, etc. from the hood linkage area, windscreen frame, door windows and rear quarter windows.

Caution:

1. Before opening the convertible top, check that there is nothing on the rear area which could interfere with the top when folded down, especially considering the heated rear window.
2. Do not attempt to operate the convertible top at temperatures below -15°C (5°F). This may cause damage to the fabric.
3. The hood may be opened or closed at speeds below 16 km/h (10 mph). If this speed is exceeded when opening, the top will continue to move to its open position. If this speed is exceeded when closing, top movement will stop and it will return to the open position.

Note: When starting a journey with the convertible top open, remove the cover if there is a possibility that whilst driving it might be necessary to close the top.

To open the convertible top:

If parked:



1. Turn ignition key to position 'I' or 'II'.

If parked or driving at less than 16 km/h (10 mph):

2. Press and hold the rear of the ROOF switch. (Do not release the switch until the top is fully open.)
3. The rear quarter windows open, an audible warning sounds, and the top unlatches and starts to move. (If the front windows are fully closed they will open partially.)
4. When the top is fully open, the audible warning sounds again and the latch closes. (If the front windows were fully closed, they will return to the fully closed position.)
5. Release the ROOF switch.
6. When parked, refit the cover.

Note: The convertible top can also be opened or closed with the door key.

8-2 Exterior Features



To close the convertible top:

If parked:

1. Remove the cover.
2. Turn ignition key to position 'I' or 'II'.

If parked or driving at less than 16 km/h (10 mph):

3. Press and hold the front of the ROOF switch. (Do not release the switch until the convertible top is fully closed and latched, and the rear quarter windows are fully closed.)
4. As the hood starts to move the audible warning will sound and the latch will open. (If the front windows are fully closed they will open partially.)
5. When the top is fully closed and latched, the audible warning sounds again and the rear quarter windows will close. (If the front windows were fully closed, they will return to the fully closed position.)
6. When the rear quarter windows are fully closed, release the ROOF switch.

Power-Operated Convertible Top – Manual Closure

Should the convertible top mechanism fail to operate, contact your nearest Jaguar Dealer.



Caution: Do not attempt to open the convertible top manually, as damage to the linkage mechanism may occur.

If necessary, the convertible top can be closed manually, as follows:

1. The convertible top operating pump is located behind the right-hand side trim panel in the luggage compartment. Pull the trim panel from the top to access the pump.
2. Turn the pump tap fully anti-clockwise (approximately 3 1/2 turns).
3. Detach the Allen key clipped next to the pump body.
4. Remove the plug from the windscreen header trim panel and insert the Allen key into the screw socket.
5. If the latch is not in the raised position (see illustration), turn the screw fully clockwise using the Allen key.
6. Holding the convertible top by the header aperture, pull forwards until it is in the closed position.

Note: Ensure that the latch is correctly engaged with the convertible top.

7. With the Allen key, turn the screw in the header trim panel anti-clockwise, until the top is securely latched.
8. Replace the Allen key and turn the pump tap fully clockwise. Refit the trim panel and plug.



8-4 Exterior Features

Convertible Top Cover

Caution:


1. When the convertible top is open, always fit the cover to prevent soiling and damage.
2. Take care to prevent the cover fixings damaging the bodywork when fitting the cover.

To fit the cover:

1. Open the luggage compartment.
2. Ensure that the convertible top is fully folded down.
3. Place the cover in position. Secure the front edge of the cover to the top of the trim panel with the two ring-pull fasteners. When fitting the fasteners, ensure that the hole in each fastener is positioned over its stud on the trim panel (A), then press firmly on the top of the fastener to secure (B).
4. Tuck the cover sides inside the body.
5. Tuck the front edge of the cover behind the rear seat (C).
6. Tuck the three straps into the gap at the luggage compartment lid hinge area. Close the lid, trapping the straps (D).

To remove the cover:

1. Open the luggage compartment.
2. Undo the two ring-pull fasteners by pulling upwards on the lifting ring of each fastener (E), then remove the cover.
3. Carefully roll the cover with the lining innermost and stow it in the bag provided.



4. Put the bag in the luggage compartment in a position where it will not be crushed. Avoid placing heavy objects on the cover as permanent damage may occur.

Index

Airbags	4-18	Climate Control System	6-1
Alarms and Audible Signals	2-10	– Air Conditioning	6-2
– Audible signals	2-10	– Air Distribution	6-5
– Error tone	2-10	– Celsius/Fahrenheit Selection	6-3
– Full alarm	2-10	– Control Panel	6-1
Anti-lock Braking System (ABS plus)	5-3	– Defrost	6-2
– Braking Techniques	5-4	– External Temperature Selection	6-4
Ashtray and Cigar Lighter	7-3	– Fan Speed	6-3
Audible Warnings	3-33	– General Information	6-1
Automatic Operation – Climate Control	6-2	– Manual Air Recirculation	6-3
Automatic Transmission	3-15	– Operating Tips	6-5
– ‘J’ Gate Selector	3-15	– System Fault Display	6-5
– Drive to Fourth	3-17	– Temperature Selection	6-2
– Gear Selector Positions	3-16	– Ventilation Airflow	6-4
– Gear-shift Interlock	3-16	Clock	3-2
– Kickdown	3-17	Column Switch	
– Reverse Inhibit	3-17	– Left-Hand	3-25
– Sport Mode	3-15	– Right-Hand	3-30
Battery Back-up Sounder	2-12	Convertible Top	8-1
Battery Condition Indicator	3-2	– Cover	8-4
Battery Tampering Alarm and Restart Procedure	2-12	– Manual Closure	8-3
Brakes	5-3	Cruise (Speed) Control	3-19
Bulb Failure Monitoring	3-28	– Changing the Set Speed	3-20
Centre Console Armrest/Storage Compartment	7-3	– Resuming a Set Speed	3-20
Child Restraint Tether Anchorages	4-21	– Setting a Speed	3-19
Child Safety	4-20	Cupholder	7-3
Cigar Lighter	7-3	Day Time Running Lights	3-25
Clearing Messages	3-9	Deadlocking	2-3
		Dipped Headlamps	3-25
		Direction Indicators	3-27

Index

- Door
 - Guard Lights 3-29
 - Locking System 2-4
 - Mirror Dipping 4-6
 - Rear View Mirrors 4-6
- Door locking/unlocking using key 2-2
- Door Mirror Adjustment 4-6
- Drive-away Door Locking 2-9
- Driving Position Memory System 4-3

- Engine
 - Coolant Temperature 3-1
 - Immobilisation 2-12
 - Oil Consumption 5-2
 - Starting and Stopping 3-17
- Entry/Exit Mode 4-5
- Exterior Lighting 3-25

- Fire Extinguishers 5-5
- First Aid Kit 5-5
- Fog Lamps 3-27
- Footrest 4-23
- Foreign Travel 5-5
- Fuel
 - Filler 4-11
 - Filler Flap Emergency Release 4-11
 - Level Gauge 3-1
 - Tank Filling 4-12

- Gear-shift Interlock – Automatic Transmission 3-16
- General Driving Information 5-1
- General Information 1-1
- Glass Break Sensing 2-12
- Global Locking 2-3
- Global Unlocking 2-4
- Glove Compartment 7-3

- Handbrake 3-29
- Hazard Warning Switch 3-28
- Headlamp
 - Auto Headlamp 3-26
 - Convenience 3-28
 - Levelling Switch 3-27
 - Main Beam 3-26
- Headlamp Powerwash 3-31
- Heated Front Screen 6-3
- Heated Rear Screen 6-3
- Horns 3-32

- Ignition/Starter Switch and Steering Lock 4-9
- Inertia Switch 4-8
 - Resetting 4-8
- Information Messages 3-9
- Instrument Illumination and Dimmer Switch 3-14
- Instruments 3-1
- Interior Door Lock Operation 2-9
- Interior Lighting 3-28
- Interior Rear View Mirror 4-7

Index

Jaguar	
– Dealers	1-1
– Diagnostic System	1-1
– Parts and Accessories	1-2
– Parts Distribution Service	1-2
Key Operation	2-8
– Door Locking System	2-4
Key-ring Transmitter	2-5
– Battery Renewal	2-6
– Button functions	2-7
– Care of	2-5
– Loss of	2-5
– Operation	2-6
Language Selection	3-9
Lighting	
– Exterior	3-25
– Interior	3-28
Limp Home Mode	3-18
Locking Wheel Nuts	1-2
Luggage Compartment – Locking and Unlocking	2-8
Luggage Retaining Net	4-24
Manual Air Distribution – Climate Control	6-4
Message Centre	3-8
Messages	3-10
Mirror	
– Door	4-6
– Interior Rear View	4-7

Mobile/Portable Telephones	1-1
Occupant Protection	
– Child Safety	4-20
– Seat Belts and Airbags	4-13
Odometer	3-8
Oil Pressure Gauge	3-2
Panic Alarm	2-11
Passive Arming	2-11
Perimeter Sensing	2-12
Power Fold-Back – Door Mirror	4-7
Radio Frequency Approval	2-13
Rear Screen Heater	6-3
Rear View Mirrors	4-6
Remote Headlamp Convenience	2-11
Remote Release Switch – Luggage Compartment	2-8
Restraint Systems	
– Inertia Reel Check	4-14
Running-in	5-3
Safety Precautions	1-3
Safety, Warning and Caution Labels	1-4
Seat Back Tilt	4-2
Seat Belts	4-13
– Care of	4-14
– Cleaning	4-14
– Front Seat Belts	4-15
– Front Seat Belts Fitting and Adjustment	4-15

Index

- Seat Belts (cont'd)
 - Inertia Reel Mechanism Check4-14
 - Rear Seat Belts4-17
- Seat Heaters4-2
- Seat Memory – Driving Position4-3
- Seats
 - Adjustment4-1
 - Adjustments and Driving Position Memory4-1
- Security Design Features2-1
- Security of Keys and Key-ring Transmitters2-1
- Security System Features2-11
- Selecting Message Centre Functions3-8
- Sidelights3-25
- Snow Chains and Spikes Spiders5-2
- Snow Tyres5-2
- Speedometer3-1
- Stability Control3-21
- Steering Column Tilt and Reach Adjustment
 - Electrical4-5
 - Manual4-4
- Steering Column Tilt Away – Entry/Exit Mode4-5
- Steering Lock
 - Disengage4-10
 - Ignition/Starter Switch4-9
- Sun Visors7-1
- Sunglasses Stowage Compartment7-3
- Tachometer3-1
- Tilt Sensing Protection2-12
- Touring5-5
- Traction Control3-21
- Traction control3-21
- Trip Computer3-12
- Trip Computer Switchpack3-13
- Tyres
 - Winter5-2
- Valet Key Locking2-11
- Valet Switch2-8
- Vanity Mirrors7-1
- Vehicle Identification1-6
- Vehicle Security2-1
- Warning and Information Messages3-9
- Warning Lights3-3
- Warning Messages3-9
- Warning Triangle5-5
- Windows
 - Automatic Drop for Door Opening3-23
 - One Touch Operation3-23
 - Rear Quarter Window Operation3-24
 - Re-programming after Power Disconnection3-23

Index

Windscreen Washers Operation	3-31
Windscreen Wipers	
– Flick Wipe	3-31
– Intermittent Wipe	3-30
– Rain Sensitive Operation	3-30
Windscreen Wipers and Washers	3-30
Winter Driving	5-2
Winter Tyres	5-2

JJM 10 02 14/00